

TROUBLE SHOOTING
DIAGNOSTIC LIST

<input type="checkbox"/>	<input type="checkbox"/>	Release valve may not be tightly closed.
<input type="checkbox"/>	<input type="checkbox"/>	Jack may be low on oil. Remove filter plug and fill reservoir with clean hydraulic jack oil.
<input type="checkbox"/>	<input type="checkbox"/>	Reservoir may be overfilled. Remove filter plug and drain excess oil.
<input type="checkbox"/>	<input type="checkbox"/>	Jack may be air-bound. Open the release valve and pump the handle several times. Close the release valve and operate. Repeat if necessary.
<input type="checkbox"/>	<input type="checkbox"/>	Valves may not be closed or have leakage either present. To leak valves, lower the saddle and close the release valve. Manually lift the saddle several inches, open the release valve and then force the saddle to lower as rapidly as possible.

TEST CERTIFICATE

Product HYDRAULIC JACK

Item _____

Inspector _____

Date Of Packing _____

MAIN TECHNICAL DATA

Model	Lifting Capacity (TONNE)	Minimum Weight (kg)	Lifting Height (mm)	Adjusting Height (mm)	Net Weight (kg)
TH008	2	180	140	40	2.0
TH009	3	190	150	40	2.4
TH010	5	210	160	50	4.0
TH014	8	220	160	60	6.2
TH016	10	230	160	60	6.9
TH018	12	240	160	60	8
TH024	15	250	160	60	8.9
TH030	20	260	160	60	11.5

HYDRAULIC JACK

OPERATION INSTRUCTIONS



WARNING: Use of this jack is for lifting purposes only. Jack should be placed on solid level ground. Always block or chock wheels and apply emergency brake. Use additional safety support devices (EX Rated Jackstands) to support vehicle load before making repairs under vehicle. Do not load jack beyond its rated capacity. Before lifting any vehicle, make sure jack is in good working order. Do not adjust the safety valve.

INSTRUCTIONS FOR USE

TO RAISE:

1. With narrow end of jack handle release valve tightly by turning it clockwise. (Fig. 1)
2. Place jack under vehicle at proper lifting location. Refer to vehicle Owner's Manual. If needed, turn the extension screw on jack counterclockwise until it comes into contact with vehicle. (Fig. 2)
3. Insert jack handle into handle socket. Pump the handle to lift vehicle to desired height. (Fig. 3)

TO LOWER:

CAUTION: LOWER VEHICLE SLOWLY: TURN RELEASE VALVE SLOWLY!

1. Remove handle-use small end to open release valve. (To open release valve turn it SLOWLY in a counter clockwise direction.)
- NOTE: DO NOT OPEN RELEASE VALVE MORE THAN ONE (1) FULL TURN**
2. When vehicle is fully lowered, remove jack. If Extension Screw has been extended, turn it clockwise until it retracts enough to move jack away from vehicle. (



MAINTENANCE:

Adding Oil/Lubrication (Fig. 4)

1. Place the jack in an upright position.
2. Lower pump and piston to full down position.
3. Remove rubber oil plug or cap.
4. Fill with GOOD GRADE VERDRAULIC OIL only. Oil level is on or at oil fill hole. (Purge system of air as described below (Purging Air from Hydraulic System).)
5. Replace rubber oil plug.
6. Lubricate pivoting joints and screw extension periodically for proper maintenance.



Purging Air from Hydraulic system.

Occasionally air bubbles become trapped inside the jack, reducing its efficiency. Bleed air out of the jack's hydraulic system as follows:

1. Open release valve/remove oil plug.
 2. Operate pump rapidly several times to force air out.
 3. Close release valve/replace oil plug.
- Jack should now operate normally. If not, repeat purging procedure as needed.


Rust Prevention.

Keep Piston, Pump, and Extension Screw in full down position when not in use. Avoid contact with moisture. If contact with moisture occurs, wipe dry and grease/lubricate all jack parts.

CAUTION:

- Read all instructions before use.
- Never exceed the jack's rated capacity.
- Jack should only be used on a solid level surface.
- Never work underneath the vehicle without using additional safety support devices (EX Rated Jack stands) to support vehicle before making repairs.
- Do not disassemble. Disassembly may result in malfunction or injury.

CONSTRUCTION DIAGRAM



1. Piston - Piston

1. Release valve lever
2. Base
3. O-Ring
4. Hydraulic cylinder
5. Ram
6. Hydraulic oil
7. Oil-tight tank
8. Extension screw
9. Top cap
10. Pump plunger
11. Pump body
12. O-Ring
13. Safety valve