


FIREPLACES & STOVES | BATHROOM FURNITURE
2kW Electric Heater c/w Thermostat Control
Suite instructions: Models 1105

User instruction for fan heater model: *These instructions should be read carefully and retained for future reference*

Important Notes

- This heater must not be located immediately below a fixed socket outlet.
- Do not use the heater in the immediate surrounds of a bath, a shower, or a swimming pool.
- **Do not cover this heater, or obstruct the air inlet or outlet, otherwise there is a risk of overheating.** 
- The heater must be cooled down completely before any maintenance
- This heater must be fixed against a vertical surface.
- Ensure the heater is placed on a firm stable surface
- Under no circumstances should the heater be used as a free standing appliance.
- After unpacking, please make sure that the appliance is intact, with no signs of damage caused by transport. If in doubt, do not use the appliance and contact the Service Centre.
- During normal operation this appliance will emit noise from the internal fan unit.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance and its handset are not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use and dangers of the appliance and handset by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance or handset
- Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are in the vicinity.
- Do not use this appliance as a primary heat source
- Ensure that furniture, curtains and other combustible materials are positioned no closer than 1m from the front of the fire.
- Although this appliance complies with safety standards, we do not recommend its use on deep pile carpets or on long hair type of rugs
- If this fire is supplied through an extension cable, please ensure that it is the only appliance plugged into the extension and that the instructions for the extension cable / reel are followed.
- CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cut out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- This appliance must be positioned so that the plug / fused spur is accessible
- In the event of a fault please disconnect the fire from the mains supply
- Warning: This appliance must be earthed.

The wires in the mains lead connected to this appliance are coloured in accordance with the following code:

GREEN and YELLOW	Earth
BLUE	Neutral
BROWN	Live

As the colour of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured Green and Yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol or coloured Green or Green and Yellow. The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Black. The wire which is coloured Brown must be connected to the terminal which is marked with letter L or coloured Red.

Fire Installation

- The fire will be supplied installed into the surround.
- Remove the 2 x Transit screws going into the hearth from rear of the fire.
- Ensure all power connections to the fire are secure.
- If the fire is to be installed in front of an existing chimney opening and there is any risk of chimney debris falling down onto the fire it is recommended that before installation the flue or opening is sealed off with non-combustible non-fibrous insulation materials. Do not install into an existing fireplace that is prone to dampness. Should it be necessary to cap and seal the chimney to prevent personal injury, a professional should be hired to do the work.
- The appliance must be positioned so that plug is accessible. Only when you are certain that you have completed the installation should you plug in and switch on at the wall socket.
- If the fire needs to be removed from the surround the fire can be lifted off the keyholes securing it to the surround.

Preparation for use

- Check that the supply voltage details on your fuel effect fire are in accordance with your electricity supply. Your fire is fitted with a plug incorporating a 13amp fuse. In the event of replacing the fuse in the plug supplied, a 13amp fuse approved by ASTA to BS 1362 must be used.
- Before switching on, please read the following operation instructions:

Coals/Pebbles:

This fire is supplied with a one piece removable fuel bed, to remove the fuel bed grip the top of the fuel bed and pull upwards, the fuel bed should slide out of position, Refitting is a reversal of the removal directions ensuring that the fuel bed sits on the angled bracket provided inside the fire.

Thermostat:

The thermostat is mounted at the right-hand side of the front face of the heater box and can be used to control the heat output to maintain a constant room temperature to suit user requirements. This will ensure that excessive heat is not produced unnecessarily.

To set the temperature:

The knob is marked with numbers to indicate the maximum and minimum temperature positions. Start with setting 9 and when the room has reached a desired level turn the knob slowly to left until the thermostat 'clicks off'. The thermostat will then maintain the room at the selected level. To increase the temperature, turn knob back to right to a higher setting.

Note: - It is possible that if the room temperature is higher than the thermostat setting it will not come into operation and the heater will remain off until the temperature of the room cools.

Operation of the Switches – Located on the right hand side of the fire

- The top switch on the right hand side (marked with a light bulb) controls the lamp.
- The lower two switches operate the fan convector heater. To use the heater the middle of the three switches marked **O/I** (**O** is off, **I** is on) should be operated first for 1 kW of heat. The bottom switch also marked **O/I** should be used together with the middle switch to give 2kW of heat.



Safety thermal cut-out

The appliance is fitted with an Electronic Safety Control (E.S.). This is a safety device, which switches off the fire if, for any reason, the appliance overheats. The E.S. Control can only be re-set after the appliance has cooled down, in order to re-set the E.S. Control proceed as follows:

- Switch off the appliance and leave for approximately 5-10 minutes.
- Switch on appliance and the E.S. Control will re-set.
- Ensure that the appliance is functioning correctly. If the E.S. Control operates again, it is advisable to have the appliance checked out by a competent Electrician.
-

CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cut out, this appliance **must not** be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

Please note that this appliance uses a motor to operate the flame effect and that it may be possible to hear it where the background noise is very low. This is normal and should not be a cause of concern.



Maintenance

WARNING: There are no internal user serviceable parts, i.e. bulbs, in this product. Under no circumstance should access be gained to the internal parts other than by a suitably qualified person.

The area around the fire should be kept free of any materials such as lint or house dust (i.e. Animal hair/ carpet fibres) that could be drawn into the internal workings of the appliance and hence affect the performance. We recommend that you clean around the fan grille housing at regular intervals. This can be done using standard vacuum cleaner and suitable attachment. Additionally regular vacuuming of the inside of the fire bottom can be done using a standard vacuum cleaner attachment by removing the fuel bed.

Please note: if the supply cord on this appliance is damaged it must be replaced by the manufacturer, Authorised Service Agent, or a qualified person to avoid a hazard.

Note: To prevent scratching of the front screen, this appliance should be cleaned with a damp cloth only.

Fault finding – symptoms and cure.

It is highly unlikely you should have a fault with your heater, but should there appear to be a problem, please refer to the following checklist of our most frequent questions from customers. If these do not answer your query please contact your retailer, or call us.

No light effect

Please check – does the heater still work? If **YES** – it will almost certainly need a new LED unit (See maintenance section)

If **NO** – has the heater cut-out operated? To protect against overheating please refer to safety cut-out section above. If still not working, first change the 13amp fuse in the plug with one which you know works. Secondly, check the wall socket by plugging a table lamp that you know works on another socket. If this does not work get an electrician to check the socket.

Electric Fire Guarantee

Be Modern Ltd (the 'Company') provides a **twenty four month** guarantee in respect of electric fire (the 'Product') ranges.

1. **The twenty four month Guarantee applies to:**
 - a. All products in the ranges manufactured by the 'Company' (but subject to the exceptions below): where
 - b. The product has been purchased and installed within the UK and in respect of
 - c. The initial installation: and in favour of
 - d. The original purchaser
2. **Proof of Purchase must be retained by the Purchaser**
3. **The twenty four month Guarantee does not apply to:**
 - a. **Damage or inferior workmanship practices whilst the 'Product' is being installed**
 - b. **Damage caused by mis-use of the 'Product' or where normal standards of care and use have not been complied with.**
 - c. **Damage through a malfunction or an inadequately installed electric fire.**
 - d. **Damage or defects due to mis-use, accident or unauthorised alterations.**
4. During the twenty four months after the 'Product' has been supplied, the Guarantee covers the make good (whether by repair or replacement at the Company's option) of defects arising from defective manufacture of materials of 'Product' covered in Para 1 all at no cost to the purchaser on the proviso:
 - a. The Product has been installed as Be Modern recommendations
 - b. The Purchaser uninstalls the Product and makes it available for collection by Be Modern.

This Guarantee does not affect your statutory rights

On requiring service the purchaser should contact the retailer who supplied your product who will assist and advise you as necessary.



This fire complies with the European Safety Standards (LVD) EN60335-2-30 and the European Electro Magnetic Compatibility (EMC) En55015, EN60555-2 and EN60555-3 which covers the essential requirements of the EEC Directives and 89/336

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Be Modern Ltd Customer Services



Tel (0191) 430 0901

Fax (0191) 430 9522