


**RECIPROCATING SAW 4951** (SW1\*4951\*\*) **4961** (SW1\*4961\*\*)



GB

ORIGINAL INSTRUCTIONS






www.skil.com


CE	4951/4961
----	-----------


GB	EU Declaration of conformity		We declare under our sole responsibility that the stated products comply with all applicable provisions of the directives and regulations listed below and are in conformity with the following standards. Technical file at:*	
	Reciprocating saw	Article number		
	4951	SW1*4951**	2006/42/EC	EN 62841-1:2015
	4961	SW1*4961**	2014/30/EU	EN 62841-2-11:2016 +A1:2020
			2011/65/EU	
				EN 55014-1: 2021
				EN 55014-2: 2021
				EN 61000-3-2: 2019+A1:2021
				EN 61000-3-3: 2013+A1:2019
				EN 63000: 2018
			SKIL <sup>°</sup>	*Skil BV Rithmeesterpark 22 A1 4838 GZ Breda The Netherlands
			Olaf Dijkgraaf Approval Manager	
			Rho-B	
			Skil BV, Rithmeesterpark 22 A1, 4838 GZ Breda, NL	
			21.10.2022	


# UK 4951/4961


Declaration of Conformit	у	We declare under our sole applicable provisions of th conformity with the following	e responsibility that the stated products comply with all e directives and regulations listed below and are in ng standards
Reciprocating saw	Article number	Technical file at: Chervon Europe Ltd., 34 E	Bridge Street, Reading, RG1 2LU, United Kingdom
4951 4961	SW1*4951** SW1*4961**	Supply of Machinery (Safety) Regulations 2008 (SI 2008/1597) Electromagnetic Compatibility Regulations 2016 (SI 2016/1091) The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (SI 2012/3032	
		EN 62841-1:2015 EN 62841-2-11:2016-	+A1:2020
		EN 55014-1:2021 EN 55014-2:2021 EN 61000-3-2:2019+A EN 61000-3-3:2013+A	
		EN IEC 63000:2018	
		SKIL	Chervon Europe Ltd., 34 Bridge Street, Reading, RG1 2LU, United Kingdom, as authorized representative (in terms of abov regulations) acting on behalf of Skil BV, Rithmeesterpark 22 A1, 4838GZ Breda, The Netherlands
		James McCrory Technical Service Mar	nager
		Janues McRoz	Ŋ
		Place of issue: Readin Date of issue: 21/10/20	0

















# ACCESSORIES

## WWW.SKIL.COM

#### GB

## **Reciprocating saw**

#### 4951/4961

## INTRODUCTION

- This tool is intended for cutting of wood, plastic, metal and building materials as well as for pruning and tree trimming; it is suitable for straight and curved cuts
- This tool is not intended for professional use
- Read and save this instruction manual ③

## TECHNICAL DATA (1)

## TOOL ELEMENTS 2

- A Switch for on/off and speed control
- B Blade clamp
- C Arrow
- D Handle
- E Barrel grip
- F Adjustable footplate
- G Fastening bolts
- H Hex key
- J Ventilation slots

## SAFETY

#### **GENERAL POWER TOOL SAFETY WARNINGS**

WARNING Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

#### Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mainsoperated (corded) power tool or battery-operated (cordless) power tool.

- 1) WORK AREA SAFETY
- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- 2) ELECTRICAL SAFETY
- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- 3) PERSONAL SAFETY
- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
- b) Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.
- 4) POWER TOOL USE AND CARE
- a) **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) Disconnect the plug from the power source and/ or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the

power tool accidentally.

- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc., in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
- 5) SERVICE
- a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

#### SAFETY INSTRUCTIONS FOR RECIPROCATING SAWS

- Hold the power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord (cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock)
- Use clamps or another practical way to secure and support the workpiece to a stable platform (holding the workpiece by hand or against your body leaves it unstable and may lead to loss of control)

#### ACCESSORIES

- SKIL can assure flawless functioning of the tool only when original accessories are used
- Use only accessories with an allowable speed matching at least the highest no-load speed of the tool

#### **BEFORE USE**

- Always check that the supply voltage is the same as the voltage indicated on the nameplate of the tool
- Avoid damage that can be caused by screws, nails and other elements in your workpiece; remove them before you start working

#### ELECTRICAL SAFETY

- Never use the tool when the cord is damaged; it must be replaced by a specially prepared cord available through the service organization.
- Use completely unrolled and safe extension cords with a capacity of 16 Amps (U.K. 13 Amps)
- Use suitable detectors to find hidden utility lines or call the local utility company for assistance (contact with electric lines can lead to fire or electrical shock; damaging a gas line can result in an explosion; penetrating a water pipe will cause property damage or an electrical shock)

#### PERSONAL SAFETY

- In case of electrical or mechanical malfunction, immediately switch off the tool and disconnect the plug
- This tool should not be used by people under the age of 16 years
- Do not work materials containing asbestos (asbestos is considered carcinogenic)
- Dust from material such as paint containing lead, some wood species, minerals and metal may be harmful (contact with or inhalation of the dust may cause allergic reactions and/or respiratory diseases to the operator or bystanders); wear a dust mask and work with a dust extraction device when connectable
- Certain kinds of dust are classified as carcinogenic (such as oak and beech dust) especially in conjunction with additives for wood conditioning; wear a dust mask and work with a dust extraction device when connectable
- Follow the dust-related national requirements for the materials you want to work with
- Keep hands away from cutting area and the blade; keep your second hand on barrel grip E ② (if both hands are holding the saw, they can not be cut by the blade)
- Do not reach underneath the workpiece (the proximity of the blade to your hand is hidden from your sight)
- Never hold piece being cut in your hands or across your leg (it is important to support the work properly to minimise body exposure, blade binding, or loss of control)
- Do not use a dull or damaged blade (bent blades can break easily or cause kickback)
- Use protective gloves when removing the blade from the tool (the saw blade may be hot after prolonged use)
- Wear protective glasses and hearing protection

#### EXPLANATION OF SYMBOLS ON TOOL

- ③ Read the instruction manual before use
- ④ Double insulation (no earth wire required)
- ⑤ Do not dispose of the tool together with household waste material

WHEN CONNECTING NEW 3-PIN PLUG (U.K. ONLY):

- Do not connect the blue (= neutral) or brown (= live) wire in the cord of this tool to the earth terminal of the plug
- If for any reason the old plug is cut off the cord of this tool, it must be disposed of safely and not left unattended

### USE

- Combined switch for on/off and speed control 6 7
  - switch on/off the tool by pulling/releasing trigger A
  - control the speed steplessly from zero to maximum by putting less or more pressure on the trigger
- Mounting saw blade (8)
  - ! disconnect the plug
  - turn blade clamp B in same direction as arrow C on tool and hold it in that position
  - insert blade (with teeth facing down or up) to full depth
  - release blade clamp B
  - push in and pull out blade to check whether it is locked correctly
- Removing saw blade (8)
  - turn blade clamp B in same direction as arrow C on tool and hold it in that position
  - pull out blade
  - release blade clamp B

- Operating the tool
  - ! securely clamp the workpiece
  - mark the cutting line on the workpiece
  - connect plug to power source
  - hold the tool with one hand on handle D 2 and the other on the insulated barrel grip E 2
  - switch on the tool
  - guide the tool along the marked cutting line
  - keep footplate F 2 firmly against the workpiece to minimize counter-force and vibration
- Holding and guiding the tool
  - ! while working, always hold the tool at the greycoloured grip area(s) (9)
  - keep ventilation slots J 2 uncovered
  - do not apply too much pressure on the tool; let the tool do the work for you
  - ! ensure that the saw blade extends beyond the work throughout the stroke 0
- Adjusting effective sawing depth (1)
- use both fastening bolts G for sliding footplate F forward/backwards in order to enlarge/reduce the effective sawing depth

## **APPLICATION ADVICE**

- Plunge cutting <sup>12</sup>
  Plunge cuts can be made in wood and other soft materials without pre-drilling a hole
  - use a thick saw blade
  - mount the blade with the teeth facing upward
  - mark desired cutting line on the workpiece
  - tilt the tool so that the blade does not touch the workpiece
  - switch on the tool and carefully engage the moving saw blade into the workpiece
  - after the blade has penetrated through the workpiece continue sawing along the marked cutting line
- ! do not make plunge cuts in metal materials
- Use the appropriate saw blades <sup>(3)</sup>
- When cutting metals, lubricate saw blade regularly with oil
- Splinter-free cutting
  - cover cutting-line with several layers of wide tape before cutting
  - always face the good side of the workpiece down
- For more information see www.skil.com

## **MAINTENANCE / SERVICE**

- This tool is not intended for professional use
- Always keep tool and cord clean (especially ventilation slots J 2)
- ! disconnect the plug before cleaning
- If the tool should fail despite the care taken in manufacturing and testing procedures, repair should be carried out by an after-sales service centre for SKIL power tools
  - send the tool undismantled together with proof of purchase to your dealer or the nearest SKIL service station (addresses as well as the service diagram of the tool are listed on www.skil.com)
- Be aware that damage due to overload or improper handling of the tool will be excluded from the warranty (for the SKIL warranty conditions see www.skil.com or ask your dealer)

## ENVIRONMENT

#### Only for EU countries

- Do not dispose of electric tools, accessories and packaging together with household waste material
- in observance of European Directive 2012/19/EC on waste of electric and electronic equipment and its implementation in accordance with national law, electric tools that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility
- symbol 6 will remind you of this when the need for disposing occurs

#### Only for UK

- Do not dispose of electric tools, accessories and packaging together with household waste material
  - in observance of on Waste Electric and Electronic Equipment Regulations 2013 (SI 2013/3113), electric tools that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility
  - symbol  $\textcircled{\sc symbol}$  will remind you of this when the need for disposing occurs

## **NOISE / VIBRATION**

#### • 4951

Measured in accordance with EN 62841 the sound pressure level of this tool is 85.0 dB(A) and the sound power level 96.0 dB(A) (uncertainty K = 5 dB), and the vibration **\*** (triax vector sum; uncertainty K = 1.5 m/s<sup>2</sup>) **\*** cutting board 22.7 m/s<sup>2</sup>

\* cutting wooden beams 17.6 m/s<sup>2</sup>

• 4961

Measured in accordance with EN 62841 the sound pressure level of this tool is 88 dB(A) and the sound power level 99 dB(A) (uncertainty K = 5 dB), and the vibration **\*** (triax vector sum; uncertainty K =  $1.5 \text{ m/s}^2$ ) **\*** cutting board 19.0 m/s<sup>2</sup>

\* cutting wooden beams 19.1 m/s<sup>2</sup>

- The vibration emission level has been measured in accordance with a standardised test given in EN 62841; it may be used to compare one tool with another and as a preliminary assessment of exposure to vibration when using the tool for the applications mentioned
  - using the tool for different applications, or with different or poorly maintained accessories, may significantly **increase** the exposure level
  - the times when the tool is switched off or when it is running but not actually doing the job, may significantly **reduce** the exposure level
  - ! protect yourself against the effects of vibration by maintaining the tool and its accessories, keeping your hands warm, and organizing your work patterns


-
-