## SLIM-LINE Interior Doors

## Fitting & Fixing Guidelines

www.curatedbyjeld-wen.co.uk



C



# CURATED by JELDWEN.

SLIM-LINE INTERIOR DOORS

### Installation, Finishing and Care Instructions

#### INTRODUCTION

Timber is a natural and sustainable product which, if properly treated, is protected from excessive changes due to variations in humidity and temperature. JELD-WEN doors are of engineered construction, with veneered faces, for greater stability. However if doors are exposed to such changes without correct treatment, movement or distortion, such as swelling, shrinking, warping or splitting may occur. Prior to finishing and hanging this door, inspect for damage and defects, DO NOT proceed to work on it if any

noticeable damage or defect is evident. Finishing and/or installation of the door constitutes acceptance of aesthetic quality.

#### IMPORTANT

- Doors must be stored flat on three level bearers and kept dry at all times
- Do not install or store the door in newly plastered rooms
- Polythene wrapping should remain on the doors until immediately before finishing and installing
- Check the door for defects or damage before installation
  DO NOT continue to install the door if any defects or damage are found
- Any door which has been modified cannot be exchanged, except doors with proven manufacturing defects
- Doors should be handled carefully with clean gloves and not dragged across each other or across other surfaces
- Doors must be sealed on ALL edges prior to installation
- Claims for twisting, bowing, shrinking, or swelling that are moisture related (while the doors are not sealed according to our guidelines) will be rejected.

#### FINISHING

These doors are fully finished and ready to hang. You may need to decorate the edges if you need to trim. In that case you can use the touch up paint provided with the door.

#### TRIMMING/INSTALLATION

If the door is to be reduced in size, an equal amount of timber should be trimmed from either side or bottom, this must never exceed **10mm in total**, **5mm each side and 6mm from the bottom.** JELD-WEN do not recommend trimming the top of the door.

JELD-WEN recommend as a minimum three 76mm (3") hinges for interior doors. Whilst checking the size in the door frame, mark hinge positions and ball latch which is included with the door. Follow the separate fitting instruction for fitting your T Bar handle set.

#### MAINTENANCE

Regular maintenance of this door should be made, to prevent breakdown of the wood finish and to protect the timber from deterioration.


In the event of this door being proven to have a manufacturing defect where a replacement is needed, the liability shall under no circumstance exceed the price of the defective door. JELD-WEN will not be held responsible for problems resulting from poor workmanship applied to doors.

#### CONDITIONS OF SALE

JELD-WEN will not be held responsible for any incidental work or problems as a result of bad storage, handling or incorrect fitting and finishing of our doors. The foregoing does not affect your statutory rights.









www.curatedbyjeld-wen.co.uk