

## FITTING AND CARE INSTRUCTIONS FOR LEVER ON ROSE DOOR FURNITURE



Thank you for choosing Urfic door handle sets for your home. This is not only a decorative product but also has technical features.

For technical reasons, to ensure smooth continuous operation and also satisfaction with the appearance of your product, please read the following instructions carefully:

**ALL URFIC LEVER ON ROSE DOOR FURNITURE IS MULTI-HOLED AND SUPPLIED WITH 2 FIXING OPTIONS - EITHER BOLT THRU FOR HOLLOW DOORS OR WOODSCREWS**

**PLEASE NOTE: SPINDLE AND BOLT THRU FIXING MAY NEED TO BE TRIMMED TO ACCOMMODATE DOOR THICKNESS**

### FITTING INSTRUCTIONS

- \* FIT TUBULAR LATCH OR LOCK AS MANUFACTURERS INSTRUCTIONS OR REMOVE EXISTING HANDLES
- \* DRILL HOLE APPROX 15MM EACH SIDE OF THE DOOR (IF NOT ALREADY DONE) TO ALLOW FOR BOSS OF LEVER FREE MOVEMENT
- \* INSERT ONE END OF SPINDLE INTO ONE SIDE OF HANDLE
- \* PUSH BAR THROUGH TUBULAR LATCH OR LOCK IN DOOR - PUSH OTHER HANDLE ON TO SPINDLE
- \* MARK HOLES AS REQUIRED - REMOVE LEVERS
- \* **FOR WOOD SCREW FIXING PILOT HOLE WHERE MARKED DO NOT DRILL COMPLETELY THROUGH DOOR**
- \* **TO USE BOLT THRU SYSTEM DRILL HOLES 6MM (1/4") COMPLETELY THROUGH DOOR**
- \* REPLACE BOTH HANDLES - INSERT & TIGHTEN SCREWS UNTIL BACK PLATE IS FIRMLY FIXED
- \* LINE UP THE 2 DIMPLES EITHER SIDE OF THE ROSE COVER PLATE WITH THE 2 CUT OUTS LEFT AND RIGHT OF THE HANDLE (6 AND 9 O'CLOCK) AND CLICK/PUSH COVER PLATE ON
- \* ADDITIONAL INFORMATION FOR BATHROOM LOCKS ONLY
- \* MARK CENTRE LOWER HOLE. REMOVE LOCK, DRILL HOLE (3/8") COMPLETELY THROUGH DOOR
- \* PUSH 5MM SPINDLE THROUGH HANDLES/LOCK, MARK AND CUT TO LENGTH REPLACE- ATTACH THUMB TURN - TIGHTEN GRUB SCREW

### THE DO'S

- \* USE ONLY A MANUAL SCREWDRIVER
- \* PUT A SMALL DROP OF OIL ON SPRING PRIOR TO FITTING
- \* USE ONLY A DAMP CLOTH AND DUSTER TO CLEAN/POLISH YOUR HANDLES
- \* DO NOT FIT TO WET PAINT OR VARNISH

### THE DO NOT'S

- \* DO NOT USE AN ELECTRIC SCREW DRIVER (THIS WILL CAUSE DAMAGE)
- \* DO NOT USE AN ABRASIVE POLISH TO CLEAN YOUR HANDLES

### TO REMOVE COVER PLATE WHEN RE-PAINTING DOOR

- \* PLACE HEAD OF SLIM SCREWDRIVER UNDER DIMPLE ON COVERPLATE (WITH A SLIM PIECE OF CARD OR PAPER UNDER SCREWDRIVER HEAD TO PROTECT DOOR) AND TWIST - COVER PLATE SHOULD LOOSEN FROM THE BACKPLATE - IF NOT, REPEAT ON OTHER SIDE OF THE COVERPLATE

### GUARANTEE

25 YEARS (all brass based products are guaranteed for both internal and external use. All other products guarantee is for internal use only)

ONLY APPLIES IF ALL MANUFACTURERS INSTRUCTIONS HAVE BEEN FOLLOWED, THE PRODUCT IS NOT MODIFIED, NEGLECTED OR MISUSED.

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS

- \* PROOF OF PURCHASE REQUIRED. REPLACEMENT DOES NOT INCLUDE COST OF LABOUR OR DAMAGE TO OTHER MATERIALS