
Fitting Instructions - Read instructions carefully before fitting and follow them for correct use

VG282-2 2 Heavy duty aluminium roof bars - Nissan NV200








TOOLS REQUIRED: 10mm & 13mm SPANNER / RATCHET


This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD. IN8093 A - IW - 03/05/2013


Van Guard Accessories Ltd Fair Oak Close, Exeter Airport Business Park, Exeter, Devon, EX5 2UL www.van-guard.co.uk












Place roof bars onto the roof brackets with the t-slot

VG282-2 - PAGE 2 OF 3



Once in position tighten all M6 fixings to 8Nm and all M8 fixings to 12Nm. Periodically check all fixings.



TIGHTEN TO 8/12Nm

NOTES:

Maximum load is 55kg per bar. Please check that the vehicle manufacturers load bearing capacity for the roof is not exceeded. (Refer to the vehicle handbook)

Periodically check all fixings.

Retain these instructions for future reference.

SUARD GUARD