## **Apex & Pent Shed Roof Kits**

How to Measure & Order your Roof Kit





## **Measure Your Roof**

After you have measured your roof as above, add a minimum of 15cm (6 inches) to each measurement. This ensures sufficient membrane to fold over the edges of the shed roof.

## Select your Shed Roof Kit

Once you're all measured up, simply find the best size from our range of Standard Shed Roof Kits. IF IN DOUBT GET THE NEXT SIZE UP! Optional edge trims are available, just be sure to make a note of which edge the water runs off. Custom Kits are also available should you not be able to find a standard kit that meets your requirements.



Long Life EPDM Membrane Vater Based Deo Adhesive Bonding Sealant for Edges