

AM150622 - AM150641 Adjustable Wall Bracket



Tools Required

Drill; 6mm masonry drill bit (6mm ceramic drill bit optional); Cross head screwdriver; Pencil; Spirit level

KEEP DIY TOOLS OUT OF THE REACH OF CHILDREN

Home Safety Advice

- It is recommended that two people fit the cabinet to ensure that it is fitted safely.
- Always take care when using an electric drill, particularly in the bathroom.
- Always check for hidden cables and pipework before drilling and take extreme care if there is any water in the working area.
- It is advisable to use a residual current circuit breaker (RCCB).
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.
- Always ensure that the drill hole passes through the central tiled area rather than through the grouted area. To prevent surface damage to the tile, mask the area around the hole with tape before drilling.
- Do not strike the product with hard or sharp objects.

Fitting Instructions

When positioning the shower head, follow the instructions provided with your shower unit.

Remove cover from bracket to reveal screw holes by sliding sections apart as shown in Fig.1.

Position bracket on wall and use as a template to mark the screw hole positions. Drill the mounting holes in wall using a 6.0mm masonry drill.

Insert wall plug flush to the surface of the wall. If fitting to a tiled surface, the wall plug should be inserted below the surface of the tile to avoid cracking the tile.

Finally, screw bracket to wall and replace cover.

