

Fitting instructions Carpet Grippers

The first thing to do is check your floor is clear of and pipes where you are to fit grippers and door threshold trims. It is not uncommon that in old houses, water and heating pipes are laid in notched joists just below the floor boards. So, if you use a nail longer than the floor board, you could go through the pipe!

Fit the door plate before fitting the carpet underlay, as the door thresholds strip should be sited directly under the door. This is so when the door is shut you, cannot see it.

Measure between the door frame and then cut the trim with a hack saw.

If the floor is wood you can simply use 10mm nails or screws. If the floor is asphalt or concrete, you can stick them down with Gripfill and leave to dry.

Fitting Gripper Rods on wood Floors

Distance from wall:

You should place the Gripper Rods approximately 10mm away from the skirting boards with the pins pointing towards the skirting boards.

Place the carpet grippers around the outside of the room

When you reach the end of each wall, cut the Grippers to size using a hack saw.

The Rods are pre nailed and hammer in the nails.