

# SMART HOME DATA CABLE TERMINATION KIT



Remove 2.5 - 3.8 cm of jacket.




Remove centre spline (CAT6).



Untwist pairs to jacket base, and align in order. Trim ends flat.



Slide cable into connector until fully seated. Verify wiring order.



Place assembly into FT-45™ tool. Squeeze handle closed.



## IDEAL INDUSTRIES EMEA

Unit 3, Europa Court, Europa Boulevard, Westbrook, Warrington, WA5 7TN. UK.  
Tel: +44 (0)1925 44 44 46, Email: [eur.sales@idealindustries.com](mailto:eur.sales@idealindustries.com), [www.idealind.com](http://www.idealind.com)

## IDEAL Industries Germany GmbH

Esslinger Strasse 7, D-70771 Leinfelden-Echterdingen, Germany

