

Eclipse Stainless Signage



Before Installation

- Ensure the selected signage has the correct instruction for the objective you are trying to achieve
- Check that you have nothing fitted into the door that the screws will foul.

Preparation

- Accurately mark the screw hole positions onto the door ensuring the screw hole positions are at '3 & 9' and are level.
- Using a drill bit accurately pilot drill your fixing positions

Fitting

- Place the sign onto the door, line up the screw holes with your prepared pilot holes and begin to secure with the screws provided.
- It is recommended that you use a screw driver to avoid rounding the screw heads.
- It is recommended that you fit one screw first and then double check the other position of screw hole on the door.