

180° Magnetic Flexible LED Work Light/Torch

Please read instructions before using this LED Inspection Lamp and retain for future reference

This LED Inspection Lamp must be fully recharged before first use to maximise battery life

240v Mains Charging:

1. Insert mains charging lead into the lamp
2. Connect the mains plug to a 220/240v AC mains socket
3. Switch on mains power - Green light on lamp will illuminate once fully recharged
4. When fully charged turn off the AC mains power and disconnect lead from the lamp

This lamp cannot be used whilst charging

12v Charging:

1. Charging lead into the lamp
2. Connect the DC plug into a 12v cigarette lighter socket
3. Green light on lamp will illuminate once fully recharged
4. When fully charged disconnect lead from the lamp and unplug lead from 12v socket

This lamp cannot be used whilst charging

Operation:

Point the lens to the direction to which you require light

1st time the power button is pressed the torch function will switch on

2nd time the power button is pressed the main lamp will turn on and the torch at the top of the lamp will turn off

3rd time the power button is pressed the main lamp will switch off

To maintain battery life please ensure lamp is recharged before battery becomes fully depleted

Never stare directly at LEDs



HL18/HL18Y
LS12 6NA