

Thank you for purchasing this Auto Perfume Dispenser which adopts CPU Technology, with reliable function, accurate timing and low power. The spraying interval and spraying timer can be changed according to the size of space, density of population and air condition. It is an ideal choice for both commercial and home use.

◆ Product structure and function


1、Display-LED power switch lights.

2、Regular spraying

3、Three-sensing
A, 24H. That work all day, spray once every 7.5-30 minutes


B, DAY. Whenever there is light at intervals of 7.5-30 minutes when sprayed once, will not spray when there is no light

C, Night. When there is no light spray once every 7.5-30 minutes, will not spray when there is light



Size	L90XW85XH220mm
Weight	323g
Power supply	two 1.5v battery
Material	ABS

◆ Installation



◆ Installation Steps


To open the cover push down on the button located on the top of the dispenser - as shown in figure A.

2. To wall mount drill one hole of 6mm diameter 30mm deep and fix the dispenser with plug + screw to the key hole slot - as shown in figure B + E.

3. Install the aromatic spray, fit back of the nozzle from the spray right to the spout location - as shown in figure B. Place the bottleneck to the groove and press the automatic spray into position - as shown in figure C.

4. Place two pieces of 1.5V20R batteries into the base (not supplied) as shown in figure A.

5. Select the time intervals required - as shown in figure D. Switch unit on and close lid.



**AIRSENZ DISPENSER MANUAL
MODEL WR-CD-6101A**

Please read user manual before using

