

Caged Outdoor Wall Light Textured Black

These instructions on wiring and installation are provided as a guideline to assist you. If at any time you are unsure of how to proceed, **please consult a qualified electrician.**

Important!

This light fitting must be connected to the supply earth. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. Light fittings should be connected to a 5 amp fused circuit. This light fitting is suitable for outdoor use only.

Before Starting

Please read through these instructions before commencing work, and keep them for future reference.

Please Take Extreme Care When Carrying Out These Instructions

Warning!

Always switch off electricity supply at the mains during installation and maintenance. We recommend that the fuse is withdrawn or the circuit breaker is switched off whilst work is in progress. **Do not just turn off at the wall switch.** All fittings must be installed in accordance with current IEE wiring regulations. During use this product gets hot - Always switch off and allow to cool before touching.

Installation:

- 1) Remove existing light fitting (if applicable) and take a note of the wiring positions.
- 2) Remove front from product by removing screws. Carefully pierce a small hole in the rubber gasket in the back of the mounting plate to allow the cable to pass through.
- 3) Thread the cable through the hole and fix the mounting plate to the wall using the screws and plugs supplied. Take care not to damage any concealed wiring.

Wiring:

- 1) Connect household brown wire (Live) to the lampholder terminal marked 'L'.
- 2) Connect household blue wire (Neutral) to the lampholder terminal marked 'N'.
- 3) Connect household earth wire (Green/yellow) to Earth fitting, marked. ⊕

Check that you have correctly identified the house wires and the connections are tight. Ensure the product is fitted in the correct orientation. Fit the front of the product back on to the mounting plate and refit screws, tighten to secure.

Fitting / Replacing the bulb .


Do not exceed specified wattage (marked on product) as this may cause the product to overheat.

Always switch off and allow product to cool before changing the bulb.

- 1) Unscrew the shade and remove.
- 2) Remove the old bulb and replace with a bulb of the same type and wattage.
- 3) Replace the shade making sure the seal is properly seated.

Care and Use

Do not use abrasive materials and cleaners on these products as this may damage the finish. Do not clean the units with a pressure washer. To prolong the life and keep your outdoor lighting in good condition, it is recommended that periodically it is cleaned using a soft cloth followed by the application of a light coating of oil, such as WD40.



Shade

The shade must be replaced if it becomes cracked or damaged. Do not use product without shade attached.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.