


## **Pro Floor Cleaning Kit**



Dual Bucket System (15 liters) with two separate compartments keep clean and dirty rinse water separate, only clean water is used on the floor. Divider with measurement marks for easy and accurate filling and dilution of chemicals. The small, compact design makes it ideal for storage or stairs need to be climbed for access. Can be carried using single handle. Side press mechanism for maximum rinse of Mop System.

Large 720 cm<sup>2</sup> mop surface provides more direct cleaning contact and more scrubbing ability for superior and more hygienic results. Combined with the Dual Bucket it reduces total cleaning time by a full 10%. Pivoting low profile head, easy to maneuver, helps to reduce bending, stretching overreaching and prevents lower back injuries. Constructed of high impact, glass-filled Polyamide to meet the demanding needs of the professional cleaner. Collapses easily with touch of the foot pedal, to rinse or change mop head.

Microfiber mop. For heavy duty cleaning using 8mm Microfibers. Size 45cm x 16cm. Microfibers are very effective cleaning fibers that clean with less water, less streaking and less effort. It picks up up to 96% Bacterias even without the use of chemicals. Absorbs enourmous amount of water for quick liquid pick-up and retention, rinses clean with almost no effort. Long lasting, durable, and can be machine washed and laundered over 500 times (or hand washed). The overlapping large surface of the mop works as a bumper and cleans all edges.



Unger Germany GmbH
Dellenfeld 35
D - 42653 Solingen
Germany
Retail@unger-europe.com
Tel. (49) 0212/2207-166
Fax (49) 0212/2207-224
www.ungerglobal.com



# **Pro Floor Cleaning Kit**



#### Step 1.

Collapse the mop by stepping on the foot pedal located on the top of the mop holder.



#### Step 2.

Rinse the mop in the front part of the bucket filled with water and chemical solution and press out the mop wet or damp depending on the floor you want to clean.



### Step 3.

Spin and drop the mop in one action to open and lock the mop head.




#### Step 4.

Mop the floor using a figure 8-pattern. Repeat STEP 1-4 regularly.



#### **Mophead Change:**

- 1. Depress the floor pedal
- 2. Collapse head
- 3. Push down the end taps and pull out the insert
- 4. Replace with clean mop head



For best results use the "S"-Sweeping motion.
That guarantees the most efficient way of floor cleaning.

Unger Germany GmbH
Dellenfeld 35
D - 42653 Solingen
Germany
Retail@unger-europe.com
Tel. (49) 0212/2207-166
Fax (49) 0212/2207-224
www.ungerglobal.com