
## Activate sensor override mode



OFF / Wyl/ Aus / Выкл / Oprit / Apagado / Desligado / Kapali ON / Wł / Ein / Bкл / Pornit / Encendido / Ligados / Açık

De-activate sensor override mode

