

Installation Instructions

Recessed Guard

Please familiarise yourself with the product before using it for the first time. Read the following instructions and safety notes carefully. Use the device as described and for the specified purposes only. Do not throw away these instructions. Include all documentation if giving the device to a third party.

This product is designed to support loft insulation matting when installed over recessed downlights. It creates an air gap around the downlight, allowing normal operation of the lamp and allowing Part L of Building Regulations to be met.

This product must be installed in accordance with the latest editions of IEE Wiring Regulations and Building Regulations. Before installing, please consider the heat generated by the lamp and ensure that the matting material that will be placed over the recessed guard is suitable for use with temperatures of up to 300 degrees C and over.

This product is only suitable for non-fire rated downlights with cut-out diameters of 50 - 90mm and a maximum height of 110mm in plasterboard ceilings.

Fitting Instructions

Ensuring the light will fit under the guard, push the guard up through the cut-out in the ceiling and secure in place by pushing the teeth into the plasterboard.

Alternatively, the guard can be installed from above the ceiling and secured.

Once the guard is securely fitted, ensure the insulation has been pushed up out of the way and fit the light as per its fitting instructions.

The guard will only support the weight of insulation; it will not support any additional weight. Please bare this in mind when installing floor panels over the insulation and walking or placing objects.

