Recycling advice



Waste electrical products should not be disposed of with house Check with your Local Authority or retailer for recycling advice. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.

Safety information

Live Voltages may be present in this unit even when turned of or when completely disconnected.

For your safety, always switch off the supply before changing lightbulbs, or cleaning

This system contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.



This bulb is protected by a shade. This part must be replaced immediately should the shade become cracked or damaged. This fitting must not be used without the shade in place.



Non-replaceable control gear



Non-replaceable light source

Instruction leaflet

Sight Plus LED Wall Light 75147







Thank you for purchasing this light fitting. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

Warning

This is a Class 1 product and must be earthed.

Please read these instructions carefully before commencing any work.

This unit must be fitted by a competent and qualified electrician.

Install in accordance with IEE Wiring regulations and current Building Regulations.

To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge.

This light fitting should be connected to a fused circuit.

If replacing an existing fitting, make a careful note of the connections.

This product is not suitable for dimming.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

These products should not be fitted to PIR circuits or short duration timed switches.

Sight Plus recessed accessory 72638 and wedge accessory 72639 are available to purchase separately for this product.

Specification

Voltage: 240V ~ 50Hz

Lamp: 2W LED Module (SMD 2835) - 136lm

IP rating: 65

Duration: 3 hours (180 minutes)
Operating Temperature : -5°C to 50°C
Maximum Operating Humidity : 10-90%

Change over Time: Approximately 1s Battery Specification: 3.6V 900mAh Ni-Cad

Battery Charge Time: 24 hours

Layout

- The mains supply cable must have a minimum cross sectional area of 1.0mm²
- This product can be ceiling or wall mounted.
- This product has special protection against the ingress of moisture and is IP65 rated.

Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, carefully note the position of each set of wires.


- Undo the two screws at the end of the unit. Remove the screws and cover and set aside.
- This unit can be mounted on the wall or ceiling.
- Unclip the front panel by pushing the quick release tabs to expose back casing.
- Drill out selected knock out and cable entry holes on the back casing of the product.

- Using the unit as a template mark the position of the fixing holes. Take care to avoid damaging any concealed wiring and pipes. The correct fixings should be used, depending upon the surface to be mounted.
- Pull the cable through the cable entry hole and seal to maintain the IP rating, and wire as detailed below.

Wiring

Maintained Wiring

Having correctly identified the wiring from your existing light fitting, pull the wire through the hole and connect to the connection block inside the product in the following way:



Check that...

- · You have correctly identified the wires
- . The connections are tight

 No loose strands have been left out of the connection block.

Cleaning Information

- We recommend cleaning with a soft dry cloth or wash with warm water or just use a damp cloth.
- Do not use abrasive materials as these will damage the finish

Operation

- This unit works in maintained mode. The light will remain lit all the time and in the event of a power failure will remain on. The unit will charge automatically.
- remove the link from between the terminals marked "SW" and connect cables to and from switch.
- Replace fuse or circuit breaker and switch on. Ensure that the source is mains (240V \sim 50Hz).
- Verify that the LED is illuminated; this confirms that the batteries are charging.

- Charge the battery for at least 24 hours before first use.
- If the LED is not illuminated then there may be no a.c. supply, the battery has not been connected properly or the internal circuit may have failed.
- The battery should be re-charged and checked every three months.
- The battery should be discharged and the duration of the lamp in emergency mode checked every six months.

Commissioning

- Reclip the front panel in place and resecure the diffuser using the screws. Ensure that the seal is correctly fitted.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.

Battery Replacement

- If after routine operation check, the lamp does not remain lit for the three hour period, a new battery pack may be required.
- Switch off the electricity at the mains, allow batteries to fully discharge then reconnect to supply and allow to charge for 24 hours.
- Test again for two hours, if light does not remain lit change the battery pack as follows:
- Undo the two screws holding the front diffuser in place.
 Remove the diffuser and set aside.
- Undo the clips holding the gear tray and fold down.
- Unplug the battery lead from the lead coming from the PCB. Remove any cable ties around the cables.
- Remove the battery pack. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

- Replace the battery with a 3.6V 900mAh Ni-Cd ONLY. Use of a different type of battery will damage the product.
- · Write current date on the new battery pack.
- Fit the new battery pack in position and re secure using the screws set aside earlier. Refit the cable ties in position and then plug battery pack into the PCB.
- Reclip the gear tray back in position, taking care not to trap any wires.
- Perform full operation check and update test record.
- Refit the diffuser. Ensure that the seal is correctly located. Tighten the screws carefully to avoid damaging the threads.
- Restore power and allow to charge for 24 hours.

Fitting/replacing bulbs

• The LED Modules in these product are non-replaceable.