

**5059340341750**




V10821 BX220IM




EN **IMPORTANT** - These instructions are for your safety. Please read through them thoroughly prior to installation and retain them for future reference.



6 mm



[01] x 1



[02] x 4



[03] x 4



## Safety

03

- For maximum security, this key lock box must be securely fixed to a wall.
- Ensure that any wall used is sufficiently strong to carry the weight of the lock box and its contents.
- Keep the lock box door close for water resistance.
- It is recommended that dials are rotated weekly to keep them in good working order.
- DO NOT install in areas where damp and condensation are present.




## Installation


1. Consideration should be given to the placing of the key lock box to ensure that it is placed in a discreet location and will not be easily found by intruders.
2. Fixing to hollow partition walls is not recommended.
3. Open the door of the cabinet position it where required and mark the mounting positions through the pre-drilled holes in the back of the key lock box.
4. Drill 4 holes which will correspond with the size of the fixings and insert the wall plugs. It is recommended that masonry drill bit is used for this step.
5. Position the key lock box over the four drilled holes and support it there whilst securing with the four screws.
6. Continue to support the key lock box whilst tightening the fixings.



# 01




# 02






# 03




# 04





### Opening the key safe for the first time


1. Slide dials cover to reveal the dials.
2. Rotate dials to the factory pre-set combination setting (0-0-0-0)
3. Push down button 1 to open the key lock box door.
4. Close the door.
5. Upset the dials to different combination to protect the code.
6. Close the dials cover.



1. Button
2. Dials
3. Dials cover

### To set your combination

- The combination must consist of 4 numbers and should be safely recorded before being set.
- Open key lock box by inputting the factory pre-set combination (0000).
- On the back of the key lock box door move the reset tab across and up to 'B'.
- Enter your personal combination. Move the tab back to position 'A' to set your personal combination. Ensure the combination you have set is correct before moving this tab.





- We take special care to select high quality materials and use manufacturing techniques that allow us to create products incorporating design and durability. This product Smith & Locke Safe has a manufacturer's guarantee of 2 against manufacturing defects, from the date of purchase (if bought in store) or date of delivery (if bought online), at no additional cost for normal (non-professional or commercial) household use.
- To make a claim under this guarantee, you must present your proof of purchase (such as a sales receipt, purchase invoice or other evidence admissible under applicable law), please keep your proof of purchase in a safe place. For this guarantee to apply, the product you purchased must be new, it will not apply to second hand or display products. Unless stated otherwise by applicable law, any replacement product issued under this guarantee will only be guaranteed until expiry of the original period guarantee period.
- This guarantee covers product failures and malfunctions provided the product was used for the purpose for which it is intended and subject to installation, cleaning, care and maintenance in accordance with the information contained in these terms and conditions, in the user manual and standard practice, provided that standard practice does not conflict with the user manual.
- This guarantee does not cover defects and damage caused by normal wear and tear or damage that could be the result of improper use, faulty installation or assembly, neglect, accident, misuse, or modification of the product. Unless stated otherwise by applicable law, this guarantee will not cover, in any case, ancillary costs (shipping, movement, costs of uninstalling and reinstalling, labour etc), or direct and indirect damage.
- If the product is defective, we will, within a reasonable time, replace or refund.
- Rights under this guarantee are enforceable in the country in which you purchased this product. Guarantee related queries should be addressed to the store you purchased this product from.
- The guarantee is in addition to and does not affect your statutory rights.

**Manufacturer:**

**UK Manufacturer:**

Kingfisher International Products Limited,  
3 Sheldon Square, London, W2 6PX,  
United Kingdom

**EU Manufacturer:**

Kingfisher International Products B.V.  
Rapenburgerstraat 175E  
1011 VM Amsterdam  
The Netherlands  
[www.kingfisher.com/products](http://www.kingfisher.com/products)

**EN** [www.diy.com](http://www.diy.com)

[www.screwfix.com](http://www.screwfix.com)

[www.screwfix.ie](http://www.screwfix.ie)

**To view instruction manuals online,  
visit [www.kingfisher.com/products](http://www.kingfisher.com/products)**