




Description – Small Garden Lantern



Installation Instructions

Luminaire Code(s) – 4L2/4100



- Please ensure that the lantern is charged for a minimum of 30 minutes before operation.
- Please ensure that the rubber USB cap is replaced after charging/discharging to maintain ingress protection.
- The Red indicator will flash every 2 seconds when battery is at 30% and every second when at 10%, then shut off.
- The green indicator will flash every second when charging and stay permanent green when fully charged.
- The fitting cannot be operated while charging

TECHNICAL FEATURES

36 SMD LED Module 4000K, 5W, 3.7V, 7800mA	USB 5Vdc 1A charger		
Built-in Rechargeable Lithium Battery Non-replaceable	Max 6-8hr	Low Power Flashing Red indicator	Battery Capacity 18650 / 2600mAh*3
IP54	ON/OFF	Max 6hr	micro usb line 1m - incl

1. This luminaire contains no serviceable parts.
2. When the LED light source reaches end of life the whole luminaire should be replaced.



Disposal of Electronic Equipment WEEE Directive 2002/96/EC

This product falls within the scope of the Waste Electrical & Electronic Equipment Directive (WEEE), which means the product should not be disposed of as normal household waste. Ensure that this luminaire and lamp is disposed of in accordance with the WEEE Directive. Contact a local Council Waste Dept. Local Amenity Site, or the DTI for further information.
RoHS - All components and materials used in this product are RoHS 2002/95/EC compliant.