

CALEX
H O L L A N D

SMART 



**Please check out our Smart playlist on Youtube
for more help and inspiration for this product.**









IOS



ANDROID




5 Years security update for App, Cloud and Tuya module firmware from date of purchase.



EN - Description

1. Status light
 - Red light solid on: the camera network is abnormal
 - Blinking red light: awaiting WiFi connection
 - Blue light solid on: camera running correctly
 - Blinking blue light: currently connecting
2. SD Card slot: Supports local SD Card storage (Max.128G)
3. Power: DC 5V +/- 10%
4. Reset: Press and hold the 'reset' for 5 seconds to reset the device (if you have modified settings, they will return to factory defaults).
5. Microphone: Captures sound for your video
6. Speaker



EN Getting started

Before you start adding this Calex Smart product, write down the name and password, including spaces and capital letters, of your WiFi network. Make sure you have a strong WiFi signal.

Note: This item only works on 2.4GHz WiFi network, not on 5GHz WiFi network. If you get a message that the product only works on 2.4 GHz networks, then you need to change your network's WiFi frequency to 2.4 GHz in the settings menu of the router. Please contact your internet provider for this.

1. Download the Calex Smart app from the Google Play Store, the Apple Store or scan the QR code.
2. Open the app. Are you using the app for the first time? Then follow the instructions on the screen to create your account.
3. Click on "+" shown in the upper right corner or "Add Device" and select the device among the list of products.
Turn the device on. The on/off switch is located at the bottom of the device. You will hear a sound and the blue indicator light on the front will start blinking. The device is now in pairing mode.
Input the WiFi password and click "Confirm". Scan the QR Code that appears in the app with the camera of the device. Hold the QR code steady at 10-15 cm in front of the camera. When the device makes a sound, follow the on-screen instructions. The set-up will be completed automatically. For more information, see our website: www.calex.eu
4. Reset: You may need to reset the product first. Locate the reset button and press it a sound is heard (5 seconds). The indicator light will start blinking. Then proceed with step 3.

Declaration of Conformity

Hereby, Calex Smart Home UK Ltd. declares that this radio equipment is in compliance with Directive 2014/53/EU and the relevant statutory requirements, produced in China and the products passed all test according to all relevant CE and UKCA standards, regulations and statutory instruments. The full text of the (EU and UKCA) Declaration of Conformity is available at the following internet address: <http://www.calex.eu>

Postal UK: 20 Gresham Street, EC2V 7JE London, United Kingdom

Postal EU: Lyonstraat 29, 3047 AJ, Rotterdam, the Netherlands

Conformity with all relevant EU Directive requirements



Safety: if applicable: only use this device for intended purpose; do not use this device if damaged or defective. If this product is damaged, especially if the cable or fitting is damaged, this product must be shut down immediately. In this case, replacement is required; before replacing, turn off power and let device cool to avoid electrical shock or burn. The adapter (if applicable) must be installed near the device, not connected to any other adapter, and easily accessible. Products may only be used in combination with the original adapter. This product should only be opened by an authorized technician when maintenance is required. Never carry out repairs yourself. To disconnect voltage: pull the plug.



Disposal, warranty, disclaimer and intended use



Removal of your product. This product is made of high quality materials and parts that can be recycled. If you see this symbol on your product, it means that the product is covered by EU Directive 2002/96 / EC. Ask your own local government about the way in which electrical and electronic products are collected separately in your region. When disposing of old products, observe local legislation and do not dispose of these products in the normal household waste. Properly disposing of old products will prevent adverse effects on the environment and public health.

Warranty: Any changes and/or modifications to the product will void the warranty. We cannot accept any liability for damage caused by incorrect use of the product. **Disclaimer:** designs and specifications might be subjected to change without notice. All logos, brands and used product references are trademarks or registered trademarks of their respective holders and hereby recognized as such.



Intended use: indoor



EN - Safety Class II: this product, or part of this product, is double insulated and does not need to be connected to an earthed socket.