

TRITON ALWAYS RECOMMEND THE USE OF GENUINE TRITON ACCESSORIES FOR USE WITH A TRITON SHOWER. FAILURE TO USE GENUINE TRITON PARTS MAY INVALIDATE YOUR GUARANTEE.

INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

Installation & Maintenance Instructions

NOT FOR USE ON ELECTRIC SHOWERS

Always use genuine Triton accessories.

When fitting your new shower head, please ensure that the installation complies with water regulations.

INSTALLATION

Flush the hose through to remove any debris that may be in the system.

Before installing the shower head check the condition of the hose; if damaged, please replace.

Feed the hose through the hose retainer or the hole in the soapdish.

IMPORTANT: It is the conical end of the hose which grips into the holder. The shower head will not fit in the holder without the hose attached.

CLEANING THE SHOWER HEAD

It is important to keep your shower head clean to maintain the performance of your shower.

Triton recommends that all products are cleaned using warm, soapy water.


DO NOT use abrasive or aggressive chemical cleaning products as this may affect the product surface and finish and invalidate your guarantee.

The shower head can be cleaned quickly by simply rubbing your fingers over the spray plate.

IT IS IMPORTANT TO KEEP THE SHOWER HEAD CLEAN TO MAINTAIN THE PERFORMANCE OF THE SHOWER. The

hardness of the water will determine the frequency of cleaning. For example, if the shower is used every day in a very hard water area, it may be necessary to clean the shower head on a weekly basis.

NOTE: This shower head is not designed to be disassembled.



TRADITIONAL FIXED SHOWER HEAD REPLACEMENT CODE

TSHMTRAD1CH