

# Universal Riser Rail Slider - 229467/229468

Please follow these fixing and care instructions to ensure that your product is fitted safely and that it retains its high quality finish. Please retain this leaflet for future reference.

**The Universal Riser Rail Slider can be adjusted to fit rail dimensions between 18mm & 25mm.**

## Product Care

To retain the best quality finish, clean product regularly with a soft damp cloth.  
Do not use abrasive or chemical cleaners, as these will damage the product.  
Do not strike the product with hard or sharp objects.

