



LEDLENSER HF4R


HF4R Core




HF4R Work




HF4R Signature




Magnetic Charge System




Battery Indicator




Low Battery Warning




Boost




Boost Overheat Warning




Transportation Lock





Tilt Mechanism



Connecting System Adapter




Helmet Adapter (HF4R Work)




Ledlenser GmbH & Co. KG
Kronenstrasse 5-7 • 42699 Solingen • Germany
Phone +49 212/5948-0 Fax +49 212/5948-200
info@ledlenser.com




HF4R Core/HF4R Work



Direct to Red Mode (HF4R Core/HF4R Work)



HF4R Signature



Direct to RGB Mode (HF4R Signature)

