



LEDLENSER HF6R


HF6R Core




HF6R Work




HF6R Signature




Magnetic Charge System




Battery Indicator




Transportation Lock




Low Battery Warning




Boost




Boost Overheat Warning




Tilt Mechanism




Connecting System Adapter




Helmet Adapter (HF6R Work)





HF6R Core/HF6R Work



Comfort Pad




Wall Holder (HF6R Work)




Ledlenser GmbH & Co. KG
Kronenstrasse 5-7 • 42699 Solingen • Germany
Phone +49 212/5948-0 Fax +49 212/5948-200
info@ledlenser.com





HF6R Core/HF6R Work




HF6R Signature



Direct to Red Mode (HF6R Core/HF6R Work)



Digital Advanced Focus System (Low Power/Mid Power/Power)



Direct to RGB Mode (HF6R Signature)

