22.5W MINI DEHUIMIDIFIER



INSTRUCTION MANUAL

IMPORTANT: PLEASE READ THESE INSTRUCTION BEFORE USING THE PRODUCT AND RETAIN FOR FUTURE USE.

This product is designed to remove excess moisture from small rooms such as studies and bathrooms. It is not intended to be disassembled or serviced by the user, except for the removable water tank. Using the product for any other purpose than described above may result in product damage and create additional risks.

Please follow the instructions carefully to ensure the safe and effective operation of the device.

PRODUCT OVERVIEW



SPECIFICATION

MODEL	**TCPWHDEHUM40001**
Rated voltage	**220-240V**
Rated frequency	**50/60Hz**
Input	**9V, 2.5A**
Rated power	**22.5W**
Dehumidification	**Approx 250ml per day**
Water Tank Capacity	**1 Litre**
Water Level Detector	**Automatic switch off when tank is full. A red indicator light will show and the unit will bleep 3 times. LED display will show code E1.**
Working environment	**+15°C, over 40%RH**
Box Contents	**Dehumidifier + power adapter** **Instruction Manual**

IMPORTANT SAFETY INSTRUCTIONS

The following should always be observed for safety:

WARNING: The air intake and outlet openings should be cleaned weekly to prevent them becoming clogged. Refer to below instructions.

WARNING. To avoid the risk of electrical shock, always make sure the product is unplugged from the electrical outlet before relocating, servicing or cleaning it.

- This product is intended for indoor, non-commercial, household use for temporarily heating residential rooms. Do not use the product for any other purpose.
- Do not leave the product unattended while it is in use. Always unplug the product from the electrical outlet when it is not being used.
- Keep the product out of the reach of children and pets. This product is not intended for use by children.
- Place the product on a flat, steady, stable, heat-resistant surface.
- Do not attempt to open the unit as it may cause electrical shock.

- Always use both hands when moving the unit to avoid tilting and potential damage.
- Use this heater only as described in this manual. Any other use is not recommended by the manufacturer as it may cause fire, electric shock or personal injury.
- Do not insert or allow other objects to enter any air intake or outlet opening as this may cause an electric shock, fire or product damage.
- To prevent a possible fire, do not block air intake opening on the back and/or the air outlet on the top of the unit to ensure smooth air flow
- Plug the product into a standard AC220V electrical outlet.
- Do not use it on soft surface, such as a bed, where air outlet may become blocked.
- Do not allow the power cord to hang (e.g. over the edge of a table or counter) or place/run the power cord under rugs, carpeting or in crowded areas where it may be tripped over or pulled.
- To disconnect the product, turn the switch off first, and then remove the plug from the electrical outlet. Pull directly on the plug; do not pull on the power cord.
- Do not put any stress on the power cord where it connects to the product, as the power cord could fray and/or break.
- Do not plug or unplug the product from the electrical outlet with a wet hand.
- Keep the power cord and product away from heated surfaces.
- Do not operate the heater with a damaged cord or plug.
- Do not place the unit directly under the power socket.
- Do not operate if the product has been dropped or damaged in any way. Please seek help from a professional service facility for electrical or mechanical adjustment, or repair.

OPERATING PANEL

ON/OFF	Press to turn dehumidifier on. Will start in low mode. Press again to turn off.
TIMER	Press to set countdown timer for 6 hours. Press again to set to 12 hours. 3rd press will set for 24 hours. Press 4th time to turn the countdown function off.
LEVEL¶	Press to turn on at the lowest setting. The "low" icon will be displayed. Press again to turn to the high setting. The "high" icon will be displayed. Press 3rd time to turn on sleep mode. The display will show a moon icon and all other lights will be turned off. Press again to start the above process again.
LIGHT	To turn on the coloured lights press once. The colours will then continuously cycle through a range of 7 colours. Press again to change to an individual colour. Keep pressing until you have selected your desired colour. To turn off at any point hold the light button until the light turns off.
HUMIDITY¶	Press to display current ambient humidity value (%). The default humidity setting value is 40% RH when first turned on. Press again to increase the humidity value by 5%. Each press will add an extra 5%. (Range is from 40% to 70%). Leave for 3 seconds to set the value to want. The display will then switch to current ambient humidity level. The display will then cycle between current ambient humidity level and set humidity value.

CLEANING THE DEHUMIDIFIER

Turn off the dehumidifier and remove from the power supply. Clean the outside by wiping with a soft, dry cloth to remove any dust or dirt. Do not use or rinse with any liquid directly to avoid causing a power failure. Regularly clean the air outlet and air inlet to prevent dust or other impurities from obstructing and affecting the air circulation. Clean the water tank by removing it from the unit, emptying and using warm water with a small amount of mild detergent. Rinse thoroughly and allow to dry before placing back into the dehumidifier.

It is recommended to clean the product every 2 months and when preparing to store the product.

MAINTENANCE AND STORAGE

Ensure the product has been turned off and the power cable is unplugged from the electrical outlet before storing. Clean the air outlet and air inlet. Remove and empty the water tank. Dry thoroughly before placing back into the dehumidifier. When the fan is not in use for a long period of time it should be protected from dust and stored in a clean, dry place. Do not place any heavy items on top of the appliance during storage as this may result in possible damage to the appliance.

DISPOSAL

Only dispose of electrical appliances as designated municipal waste facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps may prove hazardous to health.

GUARANTEE

The manufacturer provides the guarantee in accordance with the legislation of the customer's own country of residence, with a minimum of 1 year, starting from the date on which the appliance is sold to the end user.

The guarantee only covers defects in material or workmanship. The repairs under guarantee may only be carried out by an authorized service centre. When making a claim under guarantee, the original bill of purchase (with purchase date) must be submitted. The guarantee will apply only in cases of normal wear.

REGISTERED OFFICES

TCP UK Ltd, 1 Exchange Court, Cottingham Road, Corby, Northants NN17 1TY.

TCP France, Quai Gabriel P'ri, 1, Joinville Le Point, France. 94340.