EN Multi Tool 300W



EN ORIGINAL INSTRUCTIONS

IMPORTANT - These instructions are for your safety. Please read through them thoroughly prior to handling the product and retain them for future reference.

WARNING: Read the instructions before using the product!

V61125_Multi Tool 300W_BX220IM

MCB1322MLT
TTB1323MLT

EN Parts



01. x1

02. x1

03. x1

04. x1

05. x1



06. x1

07. x9
(P60*3, P80*3,
P120*3)

EN You will need

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 2 11/26/25 10:53 AM

EN Contents

EN	
Product description	4
Safety information	5
Technical specifications	16
Before you start	17
Functions & Settings	22
Operation	23
Care and maintenance	26
Guarantee	29
Declaration of conformity	30

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 3 11/26/25 10:53 AM

EN Product description







1. Flange release lever
2. On/off switch
3. Hand grip
4. Speed dial
5. Power cord with plug
6. Air vents
7. Tool holder
8. Flange bolt
9. Plunge saw blade for wood
10. Plunge saw blade for metal
11. Segment saw blade
12. Scraper
13. Sanding base plate
14. Sanding paper (P60*3, P80*3, P120*3)

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 4 11/26/25 10:54 AM

General power tool safety warnings

WARNING! Read all safety warnings, instructions, illustrations and specifications provided with this power tool. *Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.*

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1) Work area safety

a) **Keep work area clean and well lit.** *Cluttered or dark areas invite accidents.*

b) **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** *Power tools create sparks which may ignite the dust or fumes.*

c) **Keep children and bystanders away while operating a power tool.** *Distractions can cause you to lose control.*

2) Electrical safety

a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** *Unmodified plugs and matching outlets will reduce risk of electric shock.*

b) **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** *There is an increased risk of electric shock if your body is earthed or grounded.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 5 11/26/25 10:54 AM

c) **Do not expose power tools to rain or wet conditions.** *Water entering a power tool will increase the risk of electric shock.*

d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** *Damaged or entangled cords increase the risk of electric shock.*

e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** *Use of a cord suitable for outdoor use reduces the risk of electric shock.*

f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** *Use of an RCD reduces the risk of electric shock.*

3) Personal safety

a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** *A moment of inattention while operating power tools may result in serious personal injury.*

b) **Use personal protective equipment. Always wear eye protection.** *Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.*

c) **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** *Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.*

d) **Remove any adjusting key or wrench before turning the power tool on.** *A wrench or a key left attached to a rotating part of the power tool may result in personal injury.*

e) **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 6 11/26/25 10:54 AM

f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** *Loose clothes, jewellery or long hair can be caught in moving parts.*

g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of dust collection can reduce dust-related hazards.*

h) **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** *A careless action can cause severe injury within a fraction of a second.*

4) Power tool use and care

a) **Do not force the power tool. Use the correct power tool for your application.** *The correct power tool will do the job better and safer at the rate for which it was designed.*

b) **Do not use the power tool if the switch does not turn it on and off.** *Any power tool that cannot be controlled with the switch is dangerous and must be repaired.*

c) **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*

d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** *Power tools are dangerous in the hands of untrained users.*

e) **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** *Many accidents are caused by poorly maintained power tools.*

f) **Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 7 11/26/25 10:54 AM

g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** *Use of the power tool for operations different from those intended could result in a hazardous situation.*

h) **Keep handles and grasping surfaces dry, clean and free from oil and grease.** *Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.*

5) Service

a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** *This will ensure that safety of the power tool is maintained.*

Multi tool safety warnings

a) **The voltage of the power source must agree with the voltage specified on the rating label of the product.**

b) **Hold the power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord.** *Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock. Before cutting into walls, ceilings etc, ensure that there are no concealed power cables or pipes in the cavity.*

c) **Use clamps or another practical way to secure and support the workpiece to a stable platform.** *Holding the workpiece by hand or against your body leaves it unstable and may lead to loss of control.*

d) **Recommendation that the tool always be supplied via a residual current device with a rated residual current of 30 mA or less.**

e) **Wear protective gloves and never touch cutting accessory or the sanding paper while it is running.** *This poses a risk of injury.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 8 11/26/25 10:54 AM

f) **Always wear eye protection and a dust mask for dusty applications and when sanding overhead.** *Sanding particles can be absorbed by your eyes and inhaled easily and may cause health complications.*

g) **Unplug the multi tool before changing accessories or tool attachments.** *Accidental start-ups may occur if the multi tool is plugged in while changing an accessory or tool attachment.*

h) **Switch the power tool on before making contact with the workpiece and only switch the power tool off after you have removed it from the workpiece.** *The power tool can move suddenly.*

i) **Keep the gripping handles dry to ensure safe control.** *Grip the product securely so you have full control at all times.*

j) **Hold the power tool firmly with both hands and make sure you have a stable footing.** *The power tool can be more securely guided with both hands.*

k) **Double check that the accessories and tool attachments are properly fixed.** *One minute testing running in no load condition will be helpful to identify any problems.*

l) **Only use the power tool for dry sanding.** *Water entering a power tool will increase the risk of electric shock.*

m) **Do not use any worn, torn or severely clogged sanding paper.** *Damaged sanding paper can tear, fly off and injure someone.*

n) **Do not use sanding paper intended for larger sanding pads.** *Larger sanding paper will extend beyond the sanding pad causing snagging, tearing of the paper or kick-back. Extra paper extending beyond the sanding pad can also cause serious lacerations.*

o) **Ensure that no persons are at risk due to flying sparks. Remove combustible materials from the surrounding area.** *Flying sparks are created when sanding metals.*

p) **Use special precautions when sanding chemically pressure treated timber, paint that may be lead based, or any other materials that may contain carcinogens.** *A suitable breathing respirator and protective clothing must be worn by all persons entering the work area. Work should be sealed by plastic sheeting and persons not protected should be kept out until work area is thoroughly cleaned.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 9 11/26/25 10:54 AM

q) **Clean the air vents on your multi tool regularly.** *The motor's fan will draw the dust inside the housing and excessive accumulation of powdered metal may cause electrical hazards.*

r) **Disposing of dust.** *Be extremely careful of dust disposal, materials in fine particle form may be explosive. Do not throw sanding dust on an open fire. Spontaneous combustion, may in time, result from a mixture of oil or water with dust particles.*

s) **Keep hands away from the sawing area. Do not reach under the workpiece.** *Contact with the saw blade can lead to injuries.*

t) **When changing the application tool, wear protective gloves.** *Application tools can become hot when used for prolonged periods of time.*

u) **Do not scrape any dampened materials (e.g. wallpaper) or on damp surfaces.** *Water entering a power tool increases the risk of electric shock.*

v) **Do not treat the surface you will be working on with any fluids that contain solvents.** *Poisonous vapours may develop due to the materials heating up when being scraped.*

w) **Take particular care when handling scrapers and blades.** *The application tools are very sharp. Danger of injury.*

The following information applies to professional users only but is good practice for all users:

ADDITIONAL SAFETY WARNINGS FOR CONSTRUCTION DUST

The updated Control of Substances Hazardous to Health Regulations 1st October 2012 now also targets to reduce the risks associated with silica, wood and gypsum dusts.

Construction workers are one of the at-risk groups within this because of the dust that they breathe: silica dust is not just a nuisance; it is a real risk to your lungs!

Silica is a natural mineral present in large amounts in things like sand, sandstone and granite. It is also commonly found in many construction materials such as concrete and mortar. The silica is broken into very fine dust (also known as Respirable Crystalline Silica or RCS) during many common tasks such as cutting, drilling and grinding. Breathing in very fine particles of crystalline silica can lead to the development of:

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 10 11/26/25 10:54 AM

- lung cancer
- Silicosis
- Chronic Obstructive Pulmonary Disorder / Chronic obstructive pulmonary disease (COPD)

And breathing in fine particles of wood dust can lead to the development of Asthma. The risk of lung disease is linked to people who regularly breathe construction dust over a period of time, not on the odd occasion.

To protect the lung, the COSHH Regulations sets a limit on the amount of these dusts that you can breathe (called a Workplace Exposure Limit or WEL) when averaged over a normal working day. These limits are not a large amount of dust: when compared to a penny it is tiny – like a small pinch of salt:

This limit is the legal maximum; the most you can breathe after the right controls have been used.

How to reduce the amount of dust?

- Reduce the amount of cutting by using the best sizes of building products.
- Use a less powerful tool e.g. a block cutter instead of angle grinder.
- Using a different method of work altogether – e.g. using a nail gun to direct fasten cable trays instead of drilling holes first.

Please always work with approved safety equipment, such as those dust masks that specially designed to filter out microscopic particles and use the dust extraction facility at all time.

For more information please see the HSE website: http://www.hse.gov.uk/construction or http://www.hse.gov.uk/pubns/cis69.pdf

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 11 11/26/25 10:54 AM

WARNING! Some dust particles created by sawing and other construction jobs contain chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks and cement and other masonry products.
- Arsenic and chromium from chemically treated timber.

Your risk from these exposures varies, depending upon how often you do this type of work. To reduce your exposure to these dusts:

- Work in a well-ventilated.
- Work with approved protective equipment, such as those dust masks that are specially designed to filter microscopic particles.

VIBRATION

The European Physical Agents (Vibration) Directive has been brought in to help reduce hand arm vibration syndrome injuries to power tool users. The directive requires power tool manufacturers and suppliers to provide indicative vibration test results to enable users to make informed decisions as to the period of time a power tool can be used safely on a daily basis and the choice of tool.

SEE TECHNICAL SPECIFICATIONS IN THE INSTRUCTION MANUAL FOR THE VIBRATION LEVELS OF YOUR TOOL.

The declared vibration emission value should be used as a minimum level and should be used with the current guidance on vibration.

Calculating the actual period of use can be difficult and the HSE website has further information.

The declared vibration emission value has been measured in accordance with a standardised test and may be used to compare one tool with another.

The declared vibration emission value may also be used in a preliminary assessment of exposure.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 12 11/26/25 10:54 AM

WARNING! The vibration emission value during actual use of the power tool can differ from the declared value depending on the ways in which the tool is used:

- How the materials are grinded, cut or drilled.
- If the tool is in good condition and well maintained.
- Use correct accessory for the tool and ensure it is sharp and in good condition.
- The tightness of the gripping handles.
- The tool is being used as intended by its design and these instructions.

While working with this power tool, hand/arm vibrations occur. Adopt the correct working practices in order to reduce the exposure to vibration. This tool may cause hand-arm vibration syndrome if its use is not adequately managed.

WARNING! Identify safety measures to protect the operator that are based on an estimation of exposure in the actual conditions of use (taking account of all parts of the operating cycle such as the times when the tool is switched off and when it is running idle in addition to the trigger time).

Note:

- The use of other tools will reduce the users' total working period on this tool.
- Helping to minimise your vibration exposure risk. ALWAYS use sharp chisels, drills and blades.
- Maintain this tool in accordance with these instructions and keep well lubricated (where appropriate).
- Avoid using tools in temperatures of 10ºC or less. Plan your work schedule to spread any high vibration tool use across a number of days.

Health surveillance

All employees should be part of an employer's health surveillance scheme to help identity any vibration related diseases at an early stage, prevent disease progression and help employees stay in work.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 13 11/26/25 10:54 AM

Vibration and noise reduction

To reduce the impact of noise and vibration emission, limit the time of operation, use low-vibration and low-noise operating modes as well as wear personal protective equipment.

Take the following points into account to minimise the vibration and noise exposure risks:

a) Only use the product as intended by its design and these instructions.
b) Ensure that the product is in good condition and well maintained.
c) Use correct attachments for the product and ensure they are in good condition.
d) Keep tight grip on the handles/grip surface.
e) Maintain this product in accordance with these instructions and keep it well lubricated (where appropriate).
f) Plan your work schedule to spread any high vibration tool use across a longer period of time.
g) Prolonged use of the product exposes the user to vibrations that can cause a range of conditions collectively known as hand-arm vibration syndrome (HAVS) e.g. fingers going white; as well as specific diseases such as carpal tunnel syndrome. To reduce this risk when using the product, always wear protective gloves and keep your hands warm.

Emergency

Familiarise yourself with the use of this product by means of this instruction manual. Memorise the safety directions and follow them to the letter. This will help to prevent risks and hazards.

a) **Always be alert when using this product, so that you can recognise and handle risks early.** *Fast intervention can prevent serious injury and damage to property.*
b) **Switch the product off and disconnect it from the power supply if there are malfunctions.** *Have the product checked by a qualified professional and repaired, if necessary, before you operate it again.*

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 14 11/26/25 10:54 AM

Residual risks

Even if you are operating this product in accordance with all the safety requirements, potential risks of injury and damage remain. The following dangers can arise in connection with the structure and design of this product:

a) Health defects resulting from vibration emission if the product is being used over long periods of time or not adequately managed and properly maintained.
b) Injuries and damage to property due to broken tool attachments or the sudden impact of hidden objects during use.
c) Danger of injury and property damage caused by flying objects or poor tool attachments.

WARNING! This product produces an electromagnetic field during operation! This field may under some circumstances interfere with active or passive medical implants! To reduce the risk of serious or fatal injury, we recommend persons with medical implants to consult their doctor and the medical implant manufacturer before operating this product!

Symbols

On the product, the rating label and within these instructions you will find among others the following symbols and abbreviations. Familiarise yourself with them to reduce hazards like personal injuries and damage to property.

V ~	Volt, (alternating voltage)	Hz	Hertz
/min or min^{-1}	Oscillations per minute	W	Watt
n_0	No-load speed	mm	Millimetre
cm	Centimetre	m	Metre
g	Gram	kg	Kilogram
dB(A)	Decibel (A-rated)	m/s^2	Metres per second squared
	Lock / to tighten or secure.		Unlock / to loosen.
	Read the instruction manual.		
	Note / Remark.		Caution / Warning.
yyWxx	Manufacturing date code; year of manufacturing (20yy) and week of manufacturing (Wxx)		
	Always wear ear protection.		Always wear eye protection.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 15 11/26/25 10:54 AM

Wear a dust mask.

Wear face shield.

Wear tight-fitting protective clothes.

Switch the product off and disconnect it from the power supply before assembly, cleaning, adjustments, maintenance, storage and transportation.

Remove plug from the mains immediately if the cable or extension cord is entangled, damaged or cut. **DON'T TOUCH THE CORD BEFORE DISCONNECTING THE SUPPLY.**

Open flames in the work area, around the product and in the vicinity of flammable materials are prohibited!

Do not smoke in the work area, around the product and in the vicinity of flammable materials!

This product is of protection class II. That means it is equipped with enhanced or double insulation.

WEEE symbol. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.

The product complies with the applicable European directives and an evaluation method of conformity for these directives was done.

Wear protective gloves.

Wear protective, slip-resistant footwear.

EN Technical specifications

General

> **Rated voltage, frequency**	: 220-240 V~,50 Hz
> **Rated power input**	: 300 W
> **Rated no-load speed n_0**	: 15000-22000 min^{-1}
> **Oscillation angle**	: 3.5°
> **Tool holder**	: Quick change tool holder
> **Sanding pad size**	: 80*80*80 mm
> **Sanding paper fixing**	: Hook & loop
> **Protection class**	: II / ⧈
> **Weight**	: approx. 1.5 kg
> **Length of power cord**	: 2.5 m
> **Dimensions**	: approx. 290*60*100 mm

Sound values

> **Sound pressure level L_{pA}**	: 85 dB(A)
> **Uncertainty K_{pA}**	: 3 dB(A)
> **Sound power level L_{WA}**	: 93 dB(A)
> **Uncertainty K_{WA}**	: 3 dB(A)

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 16 11/26/25 10:54 AM

Hand arm vibration values

> **Sanding with sanding base plate, a_h** : 8.4 m/s²
> **Cutting with plunge saw blade**
  • **Cutting board $a_{h,B}$** : 5.3 m/s²
> **Scraping with scraper** : 3.5 m/s²
> **Cutting with segment saw blade**
  • **Cutting board $a_{h,B}$** : 7.4 m/s²
> **Uncertainty K** : 1.5 m/s²

The sound value(s) have been determined according to noise test code given in EN 62841-1 and EN 62841-2-4. The sound intensity level for the operator may exceed 80 dB(A) and ear protection measures are necessary. The declared vibration total values and the declared noise emission values have been measured in accordance with a standard test method and may be used for comparing one product with another. They may also be used in a preliminary assessment of exposure.

WARNING! The vibration and noise emission during actual use of the product can differ from the declared total value depending on the ways in which the product is used especially what kind of workpiece is processed.
The need to identify safety measures to protect the operator that are based on an estimation of exposure in the actual conditions of use (taking account of all parts of the operating cycle such as the times when the product is switched off and when it is running idle in addition to the trigger time).

Rating label explanation

MCB1322MLT = Model number
MC = **MACAllister** (brand name)
B = Voltage (220-240 V~)
1322 = Sequential Code
MLT = Multi Tool

TTB1323MLT = Model number
TT = **TITAN** (brand name)
B = Voltage (220-240 V~)
1323 = Sequential Code
MLT = Multi Tool

EN Befor e you start

Unpacking

1. Unpack all parts and lay them on a flat, stable surface.
2. Remove all packing materials and shipping devices if applicable.
3. Make sure the delivery contents are complete and free of any damage. If you find that parts are missing or show damage do not use the product but contact your dealer. Using an incomplete or damaged product represents a hazard to people and property.
4. Ensure that you have all the accessories and tools needed for assembly and operation. This also includes suitable personal protective equipment.

WARNING! The product and the packaging are not children's toys! Children must not play with plastic bags, sheets and small parts! There is a danger of choking and suffocation!

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 17 11/26/25 10:54 AM

You will need

(items not supplied)
Suitable personal protective equipment
Suitable sanding paper
Suitable tool attachment
Suitable flat head screwdriver

(items supplied)
Plunge saw blade for wood (9)
Plunge saw blade for metal (10)
Segment saw blade (11)
Scraper (12)
Sanding base plate (13)
Sanding paper (14)

NOTE: The accessories required depend on the intended application. Ask your dealer for advice.

Assembly

WARNING! The product must be fully assembled before operation! Do not use a product that is only partly assembled or assembled with damaged parts!
Follow the assembly instructions step-by-step and use the pictures provided as a visual guide to easily assemble the product!
Before using the product, familiarise yourself with the operating features read the entire instruction manual paying particular attention to the safety rules and operating procedures.
Do not connect the product to power supply before assembly.

Tool attachments

Tool attachments are available in various shapes and sizes. Below is only overview of the supplied tool attachments. Ask in store for more choices.

Tool attachment		Material	Application
Sanding base plate (13) & Sanding paper (14)		Bare or painted wood, and other surface, depending on grain size (grit) of sanding paper	Flat sanding and reaching into corners and along edges
Plunge saw blade for wood (9)		Wood, plastic, Drywall	Separating or flush/ plunge saw cutting, also for sawing close to edges, in corners and hard to reach areas
Plunge saw blade for metal (10)		Soft metals	
Segment saw blade (11)		Wood, plastic, drywall, nonferrous metals	
Scraper (12)		Paint & varnish, bonded carpet, soft adhesives, vinyl flooring, wood and other floor coverings	Scraping on hard surfaces, e. g. scraping of carpet adhesive or wallpaper

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 18 11/26/25 10:54 AM

NOTE: This product can also be used with tool attachments of other brands. Carefully read the safety warnings and observe the technical specification of the respective tool attachmetns before use and purchase.
The provided flange bolt (8) enables the product to work with compatible tool attachments, which cannot be directly installed on the tool holder (7) of this product.
Ask in store for suitable options.

Attaching tool attachment

1. Fully rotate the flange release lever (1) all the way to stop to unlock the flange bolt (8) (Fig. 1, steps 1, 2).
2. Remove the flange bolt (8) from the tool holder (7) (Fig. 1, step 3). If the connection is too tight, a flat head screwdriver can be used for assistance for the first use.



Fig. 1

3. Align the grooves on the suitable tool attachment with the ribs on the tool holder (7) at desired working position/angle (Fig. 2).



Fig. 2

4. Insert the flange bolt (8) into the tool holder (7) to keep the tool attachment in position (Fig. 3, steps 1, 2) and then close the flange release lever (1) all the way to stop with a click (Fig. 3, step 3).



Fig. 3

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 19 11/26/25 10:54 AM

5. Check that the tool attachment is reliably clamped at desired angle and make adjustment if necessary.

WARNING! Check that the tool attachments are correctly attached. Incorrect or insecurely fastened tool attachments can come loose during operation and cause a hazard.

NOTE: Depending on application needs, the plunge saw blade can also be assembled at ±90º (Fig. 4). Never adjust the saw blade pointing backwards towards the handle (Fig. 5).



Fig. 4



Fig. 5

WARNING! For safety reason, please ensure that the plunge saw blade is assembled with the correct orientation (Figs. 6 and 7).



Fig. 6



Fig. 7

Detaching or replacing tool attachment

WARNING! For all work, and when changing tool attachments, always wear protective gloves.
Some tool attachments are sharp and hot after use! Handle them with care!
Wear safety gloves when handling to avoid injuries like burns and cuts!

1. Fully rotate the flange release lever (1) all the way to stop to unlock the flange bolt (8).
2. Remove the tool attachment together with the flange bolt (8) from the tool holder (7).
3. Refit a new tool attachment and secure it on the tool holder (7).

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 20 11/26/25 10:54 AM

Sanding paper

Choosing the right sanding paper

Sanding paper is available with different grain sizes (grit). The grain size is indicated with a number on the reverse of the sanding paper, the higher the number the finer the grain size.
Select a sanding paper with a grain size (grit) suitable for how much material you want to remove. Sanding paper is suitable for paint, wood and metal.

Grain size (Grit)	Class	Application
< 80	Coarse	Removal of paint and varnish, preparation of rough surfaces.
80 - 120	Medium	For face sanding and smoothing small irregularities.
120 - 180	Fine	Finishing, cleaning plaster and water stain from wood.
> 180	Very fine	Repairing surfaces before applying paint or varnish.

1. Only use suitable sanding paper in terms of application and size. Do not use sanding paper that are bigger than the sanding pad.
2. Replace worn or damaged sanding paper immediately.
3. Start with a coarse sanding paper and finish with a fine-grained one to achieve a satisfactory result.
4. Do not use the same sanding paper on different materials, e. g. do not use the sanding paper that has been used for sanding metal to sand wood. Small metal particles remaining in the sanding paper will lead to scratches.

Removing / Replacing the sanding paper

1. Invert the multi tool on a flat surface with the sanding base plate (13) facing upwards.
2. To remove the sanding paper (14), take hold of it by an edge and pull it away from the sanding base plate (13) (Fig. 8).



Fig. 8

Assembling the sanding paper

NOTE: The surface of the sanding base plate (13) is fitted with a hook-and-loop fastening, allowing sanding paper with a hook-and-loop backing to be secured quickly and easily.

1. Remove dirt and dust from the sanding base plate (13), e.g. with a paintbrush, before attaching a new sanding paper (14).
2. Tap the hook-and-loop fastening of the sanding base plate (13) before fitting the sanding paper (14) to facilitate maximum adhesion.
3. Press the sanding paper (14) firmly onto the underside of the sanding base plate (13) (Fig. 9).



Fig. 9

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 21 11/26/25 10:54 AM

NOTE: If one corner and/or edge of the sanding paper (14) is worn, it can be re-attached and rotated by 120º to use the next corner and/or edge.

Connection to power supply

1. Make sure that the on/off switch (2) is on its off position.
2. Connect the plug of power cord (5) into a suitable power socket.

WARNING! Check the voltage! The voltage must comply with the information on the rating label!
Always use the product via a Residual Current Device (RCD) with a tripping current of max. 30 mA.

3. Your product is now ready to be used.

EN Functions & Settings

Intended use

This multi tool is designated with a rated input of 300 Watts.
This product is intended for dry sanding and cutting on wood, plastic, metal and coated surfaces, especially for sanding small surfaces (e.g. corners or edges) and plunge/flush cutting; This product must not be used for plasterboard drywalls or plaster.
This product should not be used on other materials or those harmful to health.
It can be only used for dry operation without water or other coolants.
For safety reasons it is essential to read the entire instruction manual before first operation and to observe all the instructions therein.
This product is intended for private domestic use only, not for any commercial trade use. It must not be used for any purposes other than those described.

WARNING! Always switch the product off and disconnect it from power supply before making any adjustments!

Speed dial

The orbital stroke rate can be preselected by turning of speed dial (4) (Fig. 10).
You can also set the orbital stroke rate during operation by turning of the speed dial (4).
The required orbital stroke rate is dependent on the material and the work conditions and can be determined using practical tests.

1. Turn the speed dial (4) left to a higher number (as seen from the operator's position) to increase the maximum speed.
2. Turn the speed dial (4) right to a lower number (as seen from the operator's position) to decrease the maximum speed.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 22 11/26/25 10:54 AM



Fig. 10

NOTE: Orbital stroke rate level “6” is recommended for sawing, cutting and sanding harder materials, such as wood or metal; orbital stroke rate level “4” is recommended for cutting softer materials, such as plastic.

On/off switch

NOTE: Make sure that you are able to operate the on/off switch (2) without releasing the hand grip (3).

1. Switch the product on by shifting the on/off switch (2) forward to display **“I”** marking (Fig. 11).
2. Switch the product off by shifting the on/off switch (2) backward to display **“0”** marking.



Fig. 11

EN Operation

General operation

1. Check the product, its power cord and plug as well as accessories for damage before each use. Do not use the product if it is damaged or shows wear. Take care of any problem you find or have the product checked by qualified specialist.
2. Double check that the accessories and tool attachments are properly secured.
3. Always hold the product on its handle (3). Keep the handles dry to ensure safe support.
4. Ensure that the air vents (6) are always unobstructed and clear. Clean them if necessary with a soft brush. Blocked air vents may lead to overheating and damage the product.
5. Switch the product off immediately and disconnect it from the power supply if you are disturbed while working by other people entering the working area. Always let the product come to complete stop before putting it down.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 23 11/26/25 10:54 AM

6. Do not overwork yourself. Take regular breaks to ensure you can concentrate on the work and have full control over the product.

Sanding

WARNING! During operation fine dust will be generated!
Some dusts are highly inflammable and explosive! Do not smoke during operation, keep heat sources and open flames out of the working area!
Always use a dust extraction system and wear a dust mask to protect yourself against hazards resulting from fine dust!

The material removal rate and sanding result are primarily determined by the choice of sanding paper, the preselected orbital stroke rate level and the contact pressure.

1. Ensure that the workpiece is free of obstacles like nails or screws before operation. Remove them if required. Where possible, secure smaller workpieces to prevent them from moving under the product.
2. Set the suitable orbital stroke rate by adjusting the speed dial (4).
3. Switch the product on and wait until it runs at full speed before placing it on the workpiece.
4. Hold the product with one hand on the head of housing or front section of hand grip (3) and with the other hand on the hand grip (3). For optimum results, use backward and forward strokes for even operation (Fig. 12).



Fig. 12

5. The material removal rate and sanding result are primarily determined by the choice of sanding paper, the speed and the contact pressure.
6. Move the product slowly over the surface of the workpiece, sand with the grain, in parallel overlapping strokes.
7. To remove paint or smooth very rough wood, sand across the grain at 45º in two directions, and then finish parallel with the grain.
8. Check your workpiece often. The sander is capable of removing material rapidly, especially with coarse paper.
9. Only apply as much pressure as necessary to keep the product flat on the workpiece. Higher pressure will not increase but lower the performance of the product and leads to uneven results.
10. Be sure to apply consistent contact pressure in order to increase the lifetime of the sanding paper.
11. Work with dust extraction system particularly when sanding coats of varnish as the varnish could melt and smear the surface of the workpiece and the sanding paper.
12. Keep the product moving at all times, do not sand on one spot for too long.
13. Do not use a sanding paper for other materials after it has been used to work on metal.
14. Lift the product from the workpiece before switching it off.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 24 11/26/25 10:54 AM

Cutting

WARNING! Only perform plunge cutting into soft materials such as soft wood! Never attempt to conduct any plunge cutting into hard materials such as metal! Use only the appropriate saw blade for cutting! If you are unsure when cutting, consult with an experienced person – risk of injury!
Switch the product off, let it come to a complete stop and disconnect it from the power supply if the tool attachment gets stuck in the workpiece. Only then free the jammed attachment.

The provided saw blades (9 / 10 / 11) can be used for plunge or flush cutting as shown in Fig. 13.



Fig. 13

1. Use only undamaged saw blades that are in perfect condition. Bent or dull saw blades can break, negatively influence the cut, or lead to kickback.
2. When sawing lightweight materials, take into account the statutory provisions and recommendations of the material manufacturers.
3. Mark the cutting line and ensure that the workpiece will not move during operation.
4. Ensure that the cutting depth of the saw blade is higher than the workpiece thickness.
5. Set the suitable orbital stroke rate by adjusting the speed dial (4) for cutting.
6. Switch the product on, align the saw blade with the marked cutting line and place the saw blade on the workpiece.
7. Apply light pressure and carefully lead the saw blade into the workpiece until the desired depth is reached.
8. Lift the product from the workpiece before switching it off.

Scraping

WARNING! Switch the product off, let it come to a complete stop and disconnect it from the power supply if the attachment gets stuck in the workpiece. Only then free the jammed attachment.

The provided scraper (12) can be used for scaping as shown in Fig. 14.

1. Set a higher orbital stroke rate by adjusting the speed dial (4) for scraping.
2. Switch the product on before placing the scraper on the workpiece.
3. Adjust the product to a proper scraping angle according to the material of workpiece.
4. Keep the product at a flatter angle to the workpiece when processing soft materials, such as wood. Otherwise the scraper can cut into the workpiece.
5. Move the product forward at an even speed.
6. Only apply as much pressure as necessary. Higher pressure will not increase but lower the performance of the product and leads to uneven results.
7. Lift the product from the workpiece before switching it off.



Fig. 14

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 25 11/26/25 10:54 AM

After use

1. Switch the product off, disconnect it from the power supply and let it cool down.
2. Detach the tool attachments from the tool holder (7) of the product.
3. Check, clean and store the product as described below.

EN Care and maintenance

The golden rules for care

WARNING! Always switch the product off, disconnect it from the power supply and let the product cool down before performing inspection, maintenance and cleaning work!

Only perform care and maintenance work according to these instructions! All further works must be performed by a qualified specialist!

1. Keep the product clean. Remove debris from it after each use and before storage.
2. Regular and proper cleaning will help ensure safe use and prolong the life of the appliance.
3. Inspect the product before each use for worn and damaged parts. Do not operate it if you find broken and worn parts.

WARNING! Only perform repairs and maintenance work according to these instructions! All further works must be performed by a qualified specialist!

General cleaning

1. Clean the product with a damp cloth and PH-neutral soap. Use a brush for areas that are hard to reach.
2. In particular clean the sanding base plate, tool holder, speed dial, switches, air vents after every use with a cloth and brush.
3. Remove stubborn dust with high pressure air (max. 3 bar).

NOTE: Do not use chemical, alkaline, abrasive or other aggressive detergents or disinfectants to clean this product as they might be harmful to its surfaces.

4. Check for any damage and wear. Replace worn parts as necessary or contact an authorised service centre for repair before using the product again.

Maintenance

Before and after each use, check the product and accessories or tool attachments for wear and damage. If required, exchange them for new ones as described in this instruction manual. Observe the technical requirements.

Repair

This product does not contain any parts that can be repaired by the consumer. Contact an authorised service centre or a similarly qualified person to have it checked and repaired.

Power cord

If the replacement of the supply cord is necessary, this has to be done by the manufacturer or his agent in order to avoid a safety hazard.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 26 11/26/25 10:54 AM

UK plug (for UK only)

If you need to replace the fitted plug, then follow the instructions below.
IMPORTANT: The wires in the mains lead are coloured in accordance as follows:
Blue – Neutral
Brown – Live

As the colours of the wire in the mains lead of this product may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows. The wire, which is coloured blue, must be connected to the terminal, which is marked with N or coloured black. The wire, which is coloured brown, must be connected to the terminal, which is marked L or coloured red.



WARNING! Never connect live or neutral wires to the earth terminal of the plug, which is marked with E.

Only fit an approved 5 Amp BS 1363 or BS 1363/A plug and correctly rated 13 Amp BS 1362 fuse. If in doubt, consult a qualified electrician.

NOTE: If a moulded plug is fitted and has to be removed take great care in disposing of the plug and severed cable, it must be destroyed to prevent engaging into a socket.

Spare parts / Replacement parts

The following parts of this product may be replaced by the consumer. Spare parts are available at an authorized dealer or through our customer service.

Storage

1. Switch the product off and disconnect it from the power supply before storage.
2. Clean the product as described above.
3. Store the product and its accessories in storage box and in a dark, dry, frost-free, well-ventilated place.
4. Always store the product in a place that is inaccessible to children. The ideal storage temperature is between 10 °C and 30 °C.
5. We recommend using the original package for storage or covering the product with a suitable cloth or enclosure to protect it against dust.

Transportation

1. Switch the product off, disconnect it from the power supply before transporting it anywhere.
2. Attach transportation guards, if applicable.
3. Always carry the product by its hand grip (3).
4. Protect the product from any heavy impact or strong vibrations which may occur during transportation in vehicles.
5. Secure the product to prevent it from slipping or falling over, damage and injury.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 27 11/26/25 10:54 AM

Troubleshooting

Suspected malfunctions are often due to causes that the users can fix themselves. Therefore check the product using this section. In most cases the problem can be solved quickly.

WARNING! Only perform the steps described within these instructions! All further inspection, maintenance and repair work must be performed by an authorised service centre or a similarly qualified specialist if you cannot solve the problem yourself!

Problem	Possible cause	Solution
1. Product does not start	1.1. Not connected to power supply	1.1. Connect to power supply
	1.2. Power cord or plug is defective	1.2. Check by a specialist electrician
	1.3. Other electrical defect to the product	1.3. Check by a specialist electrician
2. Product does not reach full power	2.1. Extension cord not suitable for operation with this product	2.1. Use a proper extension cord
	2.2. Power source (e. g. generator) has too low voltage	2.2. Connect to another power source
	2.3. Air vents are blocked	2.3. Clean the air vents
3. Unsatisfactory cutting result	3.1. Sanding paper / saw blade is damaged	3.1. Replace with new one
	3.2. Sanding paper / saw blade is not suitable for workpiece material	3.2. Use proper sanding paper / saw blade
4. Excessive vibration or noise	4.1. Sanding paper / saw blade is damaged	4.1. Replace with a new one
	4.2. Bolts/nuts are loosen	4.2. Tighten bolts/nuts
	4.3. Tool attachment is not properly attached or correctly assembled	4.3. Reattach/re-assemble attachment

Recycling and disposal

This symbol is known as the 'Crossed-out Wheelie Bin Symbol'.
When this symbol is marked on a product or battery, it means that it should not be disposed of with your general household waste.
Some chemicals contained within electrical/electronic products or batteries can be harmful to health and the environment.
Only dispose of electrical/ electronic/battery items in separate collection schemes, which cater for the recovery and recycling of materials contained within.
Your co-operation is vital to ensure the success of these schemes and for the protection of the environment.
For further information visit www.recycle-more.co.uk.

The product comes in a package that protects it against damage during shipping. Keep the package until you are sure that all parts have been delivered and the product is working properly. Recycle the package afterwards.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 28 11/26/25 10:54 AM

EN Guarantee

We take special care to select high quality materials and use manufacturing techniques that allow us to create products incorporating design and durability.
This product has a manufacturer's guarantee of 2 years against manufacturing defects, from the date of purchase (if bought in store) or date of delivery (if bought online), at no additional cost.
To make a claim under this guarantee, you must present your proof of purchase (such as a sales receipt, purchase invoice or other evidence admissible under applicable law), please keep your proof of purchase in a safe place. For this guarantee to apply, the product you purchased must be new, it will not apply to second hand or display products. Unless stated otherwise by applicable law, any replacement product issued under this guarantee will only be guaranteed until expiry of the original guarantee period.
This guarantee covers product failures and malfunctions provided the product was used for the purpose for which it is intended and subject to installation, cleaning, care and maintenance in accordance with the information contained in these terms and conditions, in the user manual and standard practice, provided that standard practice does not conflict with the user manual.
This guarantee does not cover defects and damage caused by normal wear and tear or damage that could be the result of improper use, faulty installation or assembly, neglect, accident, misuse, or modification of the product. Unless stated otherwise by applicable law, this guarantee will not cover, in any case, ancillary costs (shipping, movement, costs of uninstalling and reinstalling, labour etc), or direct and indirect damage.
This guarantee does not cover defects and damage caused by or resulting from:

- Normal wear and tear
- Overload, misuse or neglect
- Repairs attempted by anyone other than an authorised agent
- Cosmetic damage
- Damage caused by foreign objects, substances or accidents
- Accidental damage or modification
- Failure to follow manufacturer's guidelines
- Loss of use of the goods

If the product is defective, we will, within a reasonable time, repair or replace it.
Rights under this guarantee are enforceable in the country in which you purchased this product. Guarantee related queries should be addressed to the store you purchased this product from.
The guarantee is in addition to and does not affect your statutory rights.

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 29 11/26/25 10:54 AM

CE

(EN) EU DECLARATION OF CONFORMITY
(FR) DÉCLARATION UE DE CONFORMITÉ
(PL) DEKLARACJA ZGODNOŚCI UE
(RO) DECLARAȚIA DE CONFORMITATE UE
(ES) DECLARACIÓN UE DE CONFORMIDAD
(PT) DECLARAÇÃO DE CONFORMIDADE UE

Product/ Produit/ Produkt/Produsul/Producto/Produto

- Multi Tool 300W / Outil multifonction 300W / Wielofunkcyjne 300W / Unealtă multifuncțională 300W / Multiherramienta 300W / Multiferramenta 300W
- MCB1322MLT / TTB1323MLT
- SN: 000001-999999

Name and address of the manufacturer or his authorised representative:
Nom et adresse du fabricant ou de son mandataire:
Nazwa i adres producenta lub jego upoważnionego przedstawiciela:
Denumirea și adresa producătorului sau a reprezentantului său autorizat:
Nombre y dirección del fabricante o de su representante autorizado:
Nome e endereço do fabricante ou do respetivo mandatário:

Kingfisher International Products B.V.,
Rapenburgerstraat 175E,
1011 VM Amsterdam,
The Netherlands

This declaration of conformity is issued under the sole responsibility of the manufacturer.
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.
Niniejsza deklaracja zgodności wydana zostaje na wyłączną odpowiedzialność producenta.
Prezenta declarație de conformitate este emisă pe răspunderea exclusivă a producătorului.
La presente declaración de conformidad se expide bajo la exclusiva responsabilidad del fabricante.
A presente declaração de conformidade é emitida sob a exclusiva responsabilidade do fabricante.

Object of the declaration/Objet de la declaration/Przedmiot deklaracji/Obiectul declarației/Objeto de la declaración/Objeto da declaração

Product/Produit/Produkt/Produsul/ Producto/ Produto	Model/Modèle/Model/ Modelul/Modelo/ Modelo	EAN
Multi Tool 300W Outil multifonction 300W Wielofunkcyjne 300W Unealtă multifuncțională 300W Multiherramienta 300W Multiferramenta 300W	TTB1323MLT MCB1322MLT	5063022799920 5063022800411 5063022800169 5063022800282

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:
L'objet de la déclaration décrit ci-dessus est conforme à la législation d'harmonisation de l'Union applicable:
Wymieniony powyżej przedmiot niniejszej deklaracji jest zgodny z odnośnymi wymaganiami unijnego prawodawstwa harmonizacyjnego:
Obiectul declarației descris mai sus este în conformitate cu legislația relevantă de armonizare a Uniunii:
El objeto de la declaración descrita anteriormente es conforme con la legislación de armonización pertinente de la Unión:
O objeto da declaração acima descrito está em conformidade com a legislação de harmonização da União aplicável:

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 30 11/26/25 10:54 AM

2006/42/EC as amended Machinery Directive
2014/30/EU as amended Directive Electromagnetic compatibility
2011/65/EU as amended Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Directive 2006/42/CE relative aux machines
2014/30 / UE telle que modifiée Directive Compatibilité électromagnétique
Directive 2011/65/UE relative à la limitation de l'utilisation de certaines substances dangereuses dans les équipements électriques et électroniques

2006/42/WE w zmienionej dyrektywie maszynowej
2014/30 / UE ze zmianami Dyrektywa Kompatybilność elektromagnetyczna
2011/65/UE zgodnie z wprowadzonymi poprawkami Dyrektywa w sprawie ograniczenia stosowania niektórych niebezpiecznych substancji w sprzęcie elektrycznym i elektronicznym

2006/42/CE, astfel a fost modificată Directiva privind echipamentele
2014/30/UE, astfel a fost modificată Directiva privind compatibilitatea electromagnetică
2011/65/UE cum a fost modificată Directiva Restricțiile de utilizare a anumitor substanțe periculoase în echipamentele electrice și electronice

Directiva sobre maquinaria modificada 2006/42/CE
2014/30/UE modificada Directiva Compatibilidad electromagnética
2011/65/UE según enmendado Directiva sobre restricciones a la utilización de determinadas sustancias peligrosas en aparatos eléctricos y electrónicos

2006/42/CE como diretiva de máquinas alteradas
2014/30/UE como alteração da compatibilidade eletromagnétic
2011/65/UE conforme alterado Directiva Restrição do uso de determinadas substâncias perigosas em equipamentos eléctricos e electrónicos

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:
Références des normes harmonisées pertinentes appliquées, y compris la date de celles-ci, ou des autres specifications techniques, y compris la date de celles-ci, par rapport auxquelles la conformité est déclarée:
Odwołania do odnośnych norm zharmonizowanych, które zastosowano, wraz z datą normy, lub do innych specyfikacji technicznych, wraz z datą specyfikacji, w odniesieniu do których deklarowana jest zgodność:
Trimiteri la standardele armonizate relevante folosite, inclusiv data standardului, sau trimiteri la celelalte specificații tehnice, inclusiv data specificațiilor, în legătură cu care se declară conformitatea:
Referencias a las normas armonizadas pertinentes utilizadas, incluidas las fechas de las normas, o referencias a las otras especificaciones técnicas, incluidas las fechas de las especificaciones, respecto a las cuales se declara la conformidad:
Referências às normas harmonizadas aplicáveis utilizadas, incluindo a data da norma, ou às outras especificações técnicas, incluindo a data da especificação, em relação às quais é declarada a conformidade:

EN 62841-1: 2015+A11:2022
EN 62841-2-4:2014
EN IEC 55014-1:2021
EN IEC 55014-2:2021
EN IEC 61000-3-2:2019+A1:2021+A2:2024
EN 61000-3-3:2013+A1:2019+A2:2021

Authorized Signatory and technical file holder/ Signataire et responsable de la documentation technique autorisé/ Podmiot uprawniony do wystawienia i adres przechowywania dokumentacji technicznej/ Semnatar autorizat şi deţinătorul dosarului ethnic/ Firmante autorizado y titular del expediente técnico/Signatário autorizado e detentor da ficha técnica:

Kingfisher International Products B.V.,
Rapenburgerstraat 175E,
1011 VM Amsterdam,
The Netherlands

David Awe
Group Quality & Sustainability Director : 30/11/2025

300W Multi tool_MCB1322MLT TTB1323MLT _GB_V6_251126.indd 31 11/26/25 10:54 AM

Manufacturer :

UK Manufacturer :
Kingfisher International Products Limited
1 Paddington Square, London, W2 1GG
United Kingdom

EU Manufacturer :
Kingfisher International Products B.V.
Rapenburgerstraat 175E
1011 VM Amsterdam
The Netherlands

EN www.diy.com
www.screwfix.com
www.screwfix.ie

To view instruction manuals online, visit www.kingfisher.com/products

PL www.castorama.pl

Aby zapoznać się z instrukcją obsługi online, odwiedź stronę www.kingfisher.com/products

RO

Pentru a consulta manualele de instrucţiuni online, vizitaţi www.kingfisher.com/products