

Kewcheck R2

Instructions for use

Pre-use check: Before each use the adaptor should be inspected to ensure that it is not damaged in any way. If any damage is noticed the adaptor should be withdrawn from service and replaced.

These adaptors can be used in conjunction with a wide variety of test equipment that uses test leads terminating in 4mm safety connectors. These adaptors enable connection of insulation / continuity and multifunction testers to radial and ring socket circuits. It can save the standard time consuming practice of taking all sockets off the wall for testing.

Connect your test leads to your tester, plug in your Kewcheck R2 adaptor into the socket, then insert your test leads into the appropriate terminals of the Kewcheck R2. Conduct a test.

Warning: These adaptors should only be used for testing purposes and should not under any circumstances be used to connect other types of equipment to a mains supply.

Cleaning Instructions

To clean the adaptors wipe with a damp cloth. Use a mild soap (non detergent) if required. Take care not to allow ingress of water into the electrical connections and allow to dry thoroughly before reconnecting or use.