

FILTERSPEC®

CLEAR LENS - FMP2 VALVED

TECHNICAL
SPECIFICATION

EFFORTLESSLY COMBINES EYE & RESPIRATORY PROTECTION WITH FMP2 FILTRATION OFFERING 94% EFFICIENCY

RESPIRATORY PROTECTION

INSTRUCTIONS FOR USE

Fitting the Filterspec®:

Firstly, ensure that the mask element is in sound working order and is securely located in the Filter Holder

Pull the un-fastened elastic strap over the head and locate on the neck

Place the Filterspec® onto the face, ensuring the mask element is covering the nose and mouth and the spectacle element covers the eyes. The spectacle arms can be adjusted for both angle and length to suit the user

Pull the plastic clips around the rear of the head and attach them together

Tension the elastic straps by pulling on the free ends, through the plastic clips, until a secure seal is achieved

To check the fit, place both hands completely over the mask element and inhale vigorously

If air leaks at the edge, readjust the mask, manipulating the position of the mask and headband to affect an acceptable seal

If a proper seal cannot be achieved do not enter the contaminated area

[CLICK HERE](#)

To view how to correctly fit the Filterspec®



CLEANING & MAINTENANCE

The mask element is for single use only

The mask element should not be used for more than 8 hours continuously and should be discarded after use

The carrier can be reused for all the mask elements supplied and should then be disposed of

The Filterspec® should not be removed from its packaging until it is required for use

Use only when a concentration of contaminants are not immediately dangerous to health or life, and only in accordance with the applicable health and safety standards

When not in use or during transportation the Filterspec® should be stored in a container such that it is out of direct sunlight, away from chemicals and abrasive substances and cannot be damaged by physical contact with hard surfaces/items

The mask element is single use and should be disposed off after use, the filter holder and spectacle element can be cleaned

To clean/disinfect, rinse in 1% solution of mild detergent and dry with a soft cloth - do not use abrasive cleaners

If lens becomes scratched or damaged the spectacle element should be replaced. Under normal circumstances the spectacle element should offer adequate protection for 2-3 years

SPECTACLE FRAME:

Nylon

SPECTACLE LENS:

Polycarbonate



FILTER HOLDER:

Polyethylene

FILTER:

Man Made Fibres



CONFORMITY

Eye Protection: Meets the requirements of EN166:2001 with Class 1 optics, low energy protection at elevated temperatures (FT) and anti-fogging properties (N)

Respiratory Protection: Meets the requirements of: EN1827:1999 + A1:2009

FMP2 masks have an assigned protection factor (APF) of 10 x Workplace Exposure Limit (WEL) for fine dusts, fibres, fumes, and mists

The complete unit has EC Certificate Number 550926 issued by BSI product Services



MANUFACTURING FOR SAFETY
WWW.JSP.CO.UK



UKSALES@JSP.CO.UK
TEL: +44 (0)1993 826050



