

Introduction

The name Labgear has been associated with quality signal distribution since 1932 and the current range of amplifiers continues to uphold that tradition.

All LDA amps can carry analogue and digital TV and radio, DAB, Freeview, DVB-T and DVB-T2 HD TV signals and have:

- More efficient Switch-Mode Power Supplies which run cooler
- Improved gain flatness delivering a better balance across the performance range
- Lower noise figure for optimised signal quality
- Greater signal handling capacity to cope with more channels
- Better impedance matching and therefore improved signal transfer from amp to cable

and now

- Class 3 filtering to provide a typical 45dB protection from interference from 4G LTE800 transmissions
- Labgear amplifiers use F-type coaxial connectors for better matching and security

The fully screened general purpose 4, 6+1 and 8+1-out amplifiers feature separate inputs for VHF (Band III TV, FM and DAB digital radio) and UHF (Freeview, DVB-T and DVB-T2 HD digital TV). They also have automatic line powering on the UHF input to power a masthead pre-amplifier (LMA113R) for fringe reception areas or if you have a long cable run from aerial to amplifier.

The 6+1 and 8+1-out amplifiers have FULL (16dB) output which can either be used for very long cable runs or via a signal splitter to feed up to 8 further points.

All LDA amplifiers are compliant with the Radio Equipment Directive 2014/53/EU and meet harmonised standard EN 303 354 for product Type D, Class 3.



General Safety Precautions

To Prevent Overheating

The recommended clearances and other precautions given in these instructions must be observed to prevent overheating. In addition, units should not be positioned where they are likely to become covered by curtains, fabric or insulating material. The amp should not be left resting on a carpet.


Other precautions

These appliances are not waterproof, they are intended for indoor use only and must not be positioned where they could be exposed to dripping or splashing water. Objects containing liquids should not be placed on or near the amplifier.

To prevent fire, make sure the unit and attached cabling is installed well away from naked flames.

Mains Plug

Your amplifier is supplied with a standard mains plug already fitted, if you need to change the plug use a competent professional (ELECTSA or NICEIC) to make the connection. If you need to change the fuse use a 3 Amp fuse to BS1362 carrying the ASTA or BSI approved mark and refit the plastic fuse carrier.



	LDA204LR	LDA2061LR	LDA2081LR
Number of inputs/outputs	2/4	2/6 + Full	2/8 + Full
Frequency Ranges	VHF 87-230MHz, UHF 470-782MHz		
Gain per port	10dB	10dB/17dB Full	10dB/17dB Full
Gain flatness	+/- 1dB	+/- 1dB	+/- 1dB
Noise Figure	Typical <3.0dB	Typical <3.0dB	Typical <3.0dB
4G protection Class 3	Typical -45dB	Typical -45dB	Typical -45dB
Isolation between outlets	20dB	20dB	20dB
Max. output level (IMA3 -60dB)	90dBµV	85dBµV	85dBµV
Return Loss Input/Output	10dB/10dB	12dB/9dB	12dB/9dB
Auto Line Power on UHF	12V ~50mA		
RED, EMC and LVD	Compliant		
Built-in Power Supply	220-240V ~50Hz at <3W		
Dimensions	184 x 85 x 35mm	265 x 95 x 35mm	

Applications

These amplifiers are designed to boost and distribute the signal from an outdoor aerial. Aerials that are fitted indoors may have compromised performance with both lower signal levels and a higher pick-up of noise.

LDA amps are fitted with a Class 3 4G filter however if you wish to receive TV on Channel 60 you should use a Labgear LDL DigiLink Class 0 amplifier, you may also need a Channel 60 4G filter (currently available from at800 free of charge).

LDA amps do not have an IR return path to enable channel changing from remote locations.

Installation

Important note: please read the General Safety Precautions before installing this amplifier.

Please Note: If the "FULL" power socket is not being used it must be terminated with the 75Ω terminator supplied.

Location

Try to choose a location for the amplifier which is convenient for cable runs to the system outlets but which is not too far from the aerial. Select a cool, dry, well ventilated area which is free of any risk of dripping or splashing water. Stand on a stable flat surface (not a carpet or insulating material) or fix to a wall or sturdy upright (screws not provided). Do not allow the amp to hang on the cables.

Ensure that there is adequate space to ensure cables are not kinked when connecting (minimum 120mm radius recommended) and that above and on the free sides of the amp there is at least 25mm for ventilation. Do not cover.

Electricity supply

Each unit is supplied with a fitted mains plug with 3A fuse, if this is not suitable get a competent professional (ELECSA or NICEIC) to make the connection with an isolating switch to allow it to be disconnected when necessary.


Signal connections

Input and output connections to the amp are made using F-type (IEC 60169-24) connectors.

Connections can be made using a tool for crimp or compression connectors or by hand with twist-on connectors (see Fig.1 opposite).

Ensure that the correct size connector is used to match the size of the coax cable.

Make sure that the external connections are adequately weatherproofed to prevent water ingress which could damage your amplifier.



2 -Year Guarantee

Your amplifier is guaranteed against faulty components or poor workmanship for a period of two years from the date of purchase. This guarantee does not cover accidental or malicious damage (Including damage from natural causes such as lightning) and will be invalidated by installation or use other than in accordance with these instructions, repair or attempted repair other than by the manufacturer, or opening or removal of the case. This does not affect your statutory rights.

Labgear Reserve the right to modify their designs or specifications, In the light of future developments, without prior notice. Performance figures quoted are typical and subject to normal manufacturing and service tolerances.

This product is intended for use within the UK and Eire.

Declaration of Conformity

Hereby, Labgear declares that this amplifier for TV broadcast reception in domestic premises is in compliance with the Radio Equipment Directive 2014/53/EU.

The full Declaration of Conformity is available by contacting the following internet address: www.labgear.co.uk/DoC

Technical Support

For further help, advice or information visit

Our website www.labgear.co.uk

Technical team www.labgear.co.uk/technical

Email: technical@labgear.co.uk

or **live chat** during office hours via our website

Member



Trade Association for
Content Delivery

No. M. 1125



Labgear

Bedford MK42 0NX
www.labgear.co.uk



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.



Check with your Local Authority for recycling advice.

