

AB1P2 COMBINATION CARTRIDGES F8-512 - FORCE 8™ & 10™

TWIN FILTER CARTRIDGES FOR THE FORCE 10™ FULL FACE MASK & THE FORCE 8™ HALF FACE MASK

RESPIRATORY PROTECTION

INSTRUCTIONS FOR USE

Follow the instruction supplied to fit the filters to the mask in the correct way

Align the arrows on the mask and filter. Twist the cartridge clockwise into the facemask inlet using the easy bayonet fitting

Care must be taken to ensure that the correct filter type is selected for the work to be carried out

If in doubt as to the type of filter required seek professional advice

PERFORMANCE

Offers an assigned protection factor (APF) of 10 x Workplace Exposure Limit (WEL) against fine dusts, fibres, fumes and liquid aerosols when attached to a Force 8™. When Attached to a Force 10™ it offers an APF of 20 x WEL.

DIMENSIONS OF PRODUCT

Height: 104mm

Length: 90mm

Width: 38mm

Weight: 114g (Approx.)

PACKAGING DIMENSIONS

Inner Packaging: (Quantity: 2 Filter Per Bag)

Height: 275mm Width: 45mm Length: 150mm Weight: 249g

Outer Packaging: (Quantity: 10)

Height: 182mm Width: 246mm Length: 343mm Weight: 2.49kg

MATERIALS

Cartridge Body: ABS

Cartridge Inner: Man-made Materials

CLEANING & MAINTENANCE

Wipe with damp cloth soaked in mild detergent solution, being careful not to get any liquid inside the cartridge

Do not use abrasive substances or solvents

Cleaning the filter does not extend its life

Store unopened packs in an airtight container, out of direct sunlight away from chemicals, abrasive substances and in a dry atmosphere



CONFORMITY

Meets the requirements of EN14387 & EN143

EC Certificate Number 517068 & 518649, issued by BSI Product Certification

Markings: AB1, EN14387:2004, P2R, EN143:2000(A1:2006)



LIMITATIONS OF USE

Protection will only be offered if the cartridge is fitted correctly to an appropriate respirator

The use by date is printed on the outside of the container

The working life of the filter depends on many factors including work rate, airflow and concentration of any contaminant in the atmosphere

The filter should be changed immediately if:

- Breathing difficulties due to clogging are experienced
- Chemical breakthrough of a contaminant is detected by smell, taste or any other means
- The filter becomes damaged

Use in well ventilated areas only, which are not deficient in oxygen and do not contain explosive atmospheres

Bayonet style filters should never be made to fit masks with any other fitting type

