


Easy Fit EF-Series Alarm System

Wirefree 868MHz Yale EF-PC PIR image camera



Description:

1) Learn/Test Button with LED

Send test signal: hold and release within 3 secs. Enter test mode: hold and release 3-10 secs. It will takes 30 secs (vacate the room) to warm up before entering test mode.


Send learn signal: hold for 10 secs+. Camera flash will flash once when learn signal is sent.

- 2) Camera Flash
- 3) Camera
- 4) 2x 1.5V AA Lithium batteries
- 5) Cover tamper switch

Pack contents

- 1 x PIR image camera.
- 4 x wall plugs & screws.
- 2 x 1.5V AA Lithium batteries

Please note supervision is always enabled on this sensor (30 minutes+ interval).



Programming & installation

Program your PIR before installation and test afterwards. Please see your current system instruction book.

SPECIAL NOTE:

When inserting new batteries, the followings are disabled for 5 minutes:

- 1) Tamper switch
- Image will not be sent during the first 5 minutes.

Please make sure you do not trigger the PIR image camera for 5 minutes before testing the system.

Operation

Sleep Timer

The PIR features an automatic "sleep time" of approximately one minute for power conservation. After transmitting a detected movement, the PIR will not retransmit for one minute. Any further movement detected within this one-minute sleep period will extend the sleep time by another minute. Disable the sleep timer temporarily by entering the test mode. See Enter test mode. Use the "walk test" function on the Yale Home System app to check for triggered activities.

LED indicator	
Off	Normal operation
LED flash (2 sec)	- Detects motion during Low battery, Tamper activated or Test mode.

WARNING:

When you delete the PIR image camera from the system, please ensure the PIR batteries are removed to avoid necessary drain.

Specification

Environmental conditions:

-10c to 40c, relative humidity 85% noncondensing. Indoor use only

Radio: 2.4GHz











2 Year Instruction Statement:

This product is guaranteed for consumers against faulty workmanship, materials and function for a period of 2 years from the date of purchase providing the full installation and maintenance instructions are followed. Please keep your proof of purchase safe, this must be submitted when making a claim under this quarantee.

Please note that it is a condition of this guarantee that your Yale product:

- · Has been correctly installed and maintained in accordance with the Yale installation and maintenance instructions provided to you at the time of purchase.
- Has not been modified or damaged in any way.
- Has not been subjected to unauthorized repairs.

Yale are responsible under this guarantee for repairing the product or replacing the product as we deem necessary. If there is fault with the product, please contact Customer Services on 01902 364647, who will give you the name of an expert and confirm what you need to do to make a claim under this quarantee.

Please do not carry out any repairs without our authority or by using an unauthorised expert. Any repairs or other works carried out without our authorization or by using an unauthorized expert will not be covered under this guarantee.

This guarantee is non transferrable and applies to products purchased in the United Kingdom only. This guarantee does not apply to normal wear and tear. This does not affect your statutory rights. A full copy of the product instructions are available upon request or by visiting our website www.yale.co.uk.



Note: Waste electrical products and batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.