

Back To Flat!

Anaglypta®
SINCE 1887

wallrock thermal liner




- Significantly reduces heat loss and room warm up times
- Combats condensation and mould formulation for a healthier home
- Covers damaged plaster and textured surfaces
- Contains no PVC or fibreglass

- Combats condensation and mould formulation ✓
- Covers cracked plaster and textured surfaces ✓
- Produces a smooth surface for decorating ✓
- Contains no PVC or fibreglass ✓
- Reduces room warm up times ✓
- Allows your walls to breathe ✓
- Significant energy savings ✓
- Sound Insulating ✓

R Value 0.05 m²K/W
U Value 12.19 W/m²K
A Value 0.038 W/m.K



Paste Consumption Guide
5kg (11lb) of adhesive per roll*



ERFURT **mav**

Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK Helpline (UK) : +44 (0)1427 616597

www.anaglypta.co.uk

Tips to achieve a perfect finish with Wallrock Thermal Liner

- Draw a guideline to be able to hang the Wallrock Thermal Liner straight.
- Apply Wallrock Thermal Liner Adhesive to the wall using a roller.
- Hang the Thermal Liner and smooth down with a brush or roller.
- Trim off any excess and allow to dry naturally for 24 hours.
- For superior finish overhang with Wallrock Fibreliner.
- Once dry surface is now ready for painting or overhanging with a printed wallpaper.

CE	
Retford Wallcoverings Limited Unit 28, Carringham Road Industrial Estate, Gainsborough, DN21 1QB UK CPD-0012	
EN 15102: 2007 + A1 -2011 Wall Lining	
Reaction to fire class	E
Release of Formaldehyde	PASS
Release of other Dangerous Substances - Of heavy metals and specific elements - Of vinyl chloride monomer (VCM)	PASS
Sound Absorption	NPD
Thermal Resistance	NPD

Pattern nr.
Batch nr.



wallrock[®] thermal liner

- Covers cracked plaster and textured surfaces
- Resists mould formation for a healthier home
- Produces a smooth surface for decorating
- Contains no PVC or fibreglass
- Reduces room warm up times
- Allows your walls to breathe
- Significant energy savings
- Sound insulating

Paste Consumption Guide

5kg (11lb) of adhesive per roll*

*The adhesive consumption indication is for guidance only, on walls in good condition less paste may be required whereas on damaged or textured walls and surfaces that are not vertical, more paste may be required.

Important


Every effort is made to ensure all rolls reach you in perfect condition, but faults can occur from time to time. Before hanging please check that each roll of **Wallrock Thermal Liner** is undamaged. Please retain all labels, we will require them if you have a problem. We recommend that after hanging no more than 2 lengths that the result is inspected before continuing. We cannot accept claims for consequential loss in respect of visible defects apparent prior to hanging. If a fault is found please return any defect roll/s with label/s to where it was purchased.

Warning


To minimise the hazard in the event of fire, do not apply wallcoverings over expanded polystyrene veneers and ensure the wallcoverings are always firmly stuck down as loose wallcoverings may contribute to the hazard. Surfaces painted prior to 1960 may contain lead pigments and special precautions should be taken when preparing these surfaces.

This product should not be used for projects such as new builds and extensions where building regulations are applicable.

Hanging Instructions




Ensure that base surfaces are clean, dry, firm and free from any loose or flaking material. **Wallrock Thermal Liner** can also be applied in some circumstances directly over cracked and light to medium textured surfaces which are firmly adhered and stable - in such cases it is always advisable to cover a small test area before continuing.




Apply the **Wallrock Thermal Liner Adhesive** generously to the wall using a roller. Use a brush or spatula to apply adhesive to areas the roller cannot reach. On textured or damaged surfaces it is especially important to apply a generous layer of adhesive. Apply enough adhesive to apply one length of **Wallrock Thermal Liner** at a time ensuring the pasted area exceeds the width of the **Wallrock Thermal Liner** (see paste consumption guide).



Always apply **Wallrock Thermal Liner** with the smooth Wallrock face to the outside, furry side to the wall. Apply **Wallrock Thermal Liner** directly from the roll onto the wet adhesive and slide into place. Smooth out any bubbles with a roller or similar. Leave a small amount of surplus material for trimming where necessary.



Cut off any excess **Wallrock Thermal Liner** at the ceiling, floors and corners using a trimming knife with a hooked blade in combination with a forming board. Alternatively carefully mark the **Wallrock Thermal Liner** using a pencil and trim with scissors. On external corners a 'corner profile' can be used to give a neat finish or flexible filler can be used to caulk the exposed edge of **Wallrock Thermal Liner** - especially important if you intend to paint the thermal liner without applying Wallrock Fibreliner




Allow at least 24 hours for drying, longer if conditions are especially humid or cold. Wherever possible we also recommend that the thermal liner is allowed to dry out naturally and therefore the heating is turned off whilst the adhesive dries out. However if temperatures are likely to drop below 10°C/50°F it is advisable that low level heating is used to ensure that the adhesive can cure effectively.



If you do not intend to cover the product with Wallrock Fibreliner or similar then any small gaps at seams and corners can be filled and sanded prior to painting the surface directly with standard emulsion paint. Use a good quality, flexible non shrinking filler.



To create a superior finish for paint or printed wallpaper we recommend that **Wallrock Thermal Liner** is lined over with 'Wallrock Fibreliner', (this product is very strong and dimensionally stable and compliments the Thermal Liner perfectly). Other 'Paste-The-Wall' linings may be compatible but on no account should you line the product with a traditional lining as problems with lifting at seams may be encountered. NB; If applying a printed or textured wallpaper directly to **Wallrock Thermal Liner**, fill any open seams and gaps first and ensure a 'Paste-The-Wall' product is used.



Anaglypta[®]
SINCE 1887

ERFURT **mav**

Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK

Helpline (UK) : +44 (0)1427 616597

www.anaglypta.co.uk