

# Installation Instructions



Ancillary Components	
2	Blank Plug
1	Air Vent Plug
4	Bracket (a)
8	Wall Plug (b)
8	Coach Screw (c)
4	Bracket Buffer (d)

**PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE COMMENCING INSTALLATION.**

**PLEASE CHECK THAT ALL ANCILLARY COMPONENTS ARE PRESENT AND THAT THE PRODUCT HAS NOT SUFFERED ANY DAMAGE DURING TRANSIT.**

**THIS PRODUCT IS MANUFACTURED FROM ALUMINIUM & IS ONLY SUITABLE FOR INSTALLATION WITHIN A CENTRAL HEATING SYSTEM WITH A CORROSION INHIBITOR ADDED TO THE WATER.**

Installation should be carried out by a suitably qualified professional or other fully competent person & in accordance with the relevant British and European standards (BS7593:2006, EN12828:2003, EN12831:2003 & EN14336:2004) & all applicable Building Regulations.


When drilling or fixing into walls, floors or ceilings it is essential that you check for pipes & wires before commencing. Please ensure that you wear all necessary personal protective equipment. Due to our commitment to continuous product development we reserve the right to alter specifications without prior notice.

Regular cleaning with a soft cloth will keep the surface of your product looking new. Soapy water can be used to remove stubborn marks. Do not use abrasive or chemical cleaners as these will damage the surface finish over time.



Instruction:

1. Wind a thick layer (at least 6 turns) of PTFE tape, clockwise around the radiator valve tails (not supplied) and screw the radiator valve tails into the bottom two threads and tighten firmly.
2. Check that the wall is strong enough to hold the weight of the radiator filled with water. On plasterboard walls we strongly recommend fixing to the timbers.
3. The wide side of the Brackets should be against the wall. Mark the Bracket positions on the wall and then use one of the Brackets to mark the top slot positions. The bottom hole of the lower brackets should be at least 290mm above the finished floor level so that the bottom of the radiator is at least 150mm above the finished floor level.
4. Drill the top holes in the middle of the slot markings, for the fixings you intend to use. The Wall Plugs supplied are only suitable for solid walls and you will need alternative fixings for other wall types. Screw the Brackets to the wall through the top slot and level the Brackets horizontally and vertically. Mark the bottom hole position through the Bracket and then swivel the Bracket out of the way to drill the bottom holes. Using the slot at the top allows for initial adjustment and using the hole at the bottom prevents vertical movement. Screw the bottom fixings through the bottom hole in the Bracket and tighten all 4 fixings.
5. Place the plastic Bracket Buffers into the slots on the Brackets.

Wall Fixing Set includes;	
4	Bracket (a)
4	Plastic buffer (b)
8	Wall Screw (c)
8	Wall Plug (d)



Bleed valves come installed on the radiator



Tappings = Width + Valves