

Calculate how many fixed sized doors you need

Use the table to find out which fixed sized doors and tracksets work best with your opening space.

Classic & Contour door frame width - 35mm

Ideal opening width* for 2 doors = (2 x Door width) – (1 x Overlap)

Ideal opening width* for 3 doors = (3 x Door width) – (2 x Overlaps)

Ideal opening width* for 4 doors = (4 x Door width) – (2 x Overlaps)

*The 'ideal opening width' is the best opening width that allows for the door frames to perfectly overlap.

Example 3 door opening - using X3 762mm wide doors


762 x 3 = 2286mm. Minus X2 overlaps at 35mm each (70mm) = **2216mm Opening**

Number of overlaps required:

2 door opening



3 door opening



4 door opening

